


# IndraMotion MLC and IndraLogic XLC



# Agenda

- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information

# System Topology



# IndraMotion MLC – Hardware platforms



### IndraControl L

- Scalable hardware platform L25 – L45 – L65/L75
- Sercos on board
- PROFINET, EtherNet/IP on board
- PROFIBUS on board



### IndraControl XM2

- Scalable hardware platform XM21 – XM22
- Sercos on board
- USB Device – Programming interface
- USB Host – Storage
- SD card for Backup & Restore

≥ MLC14




### IndraControl V

- High-performance IPC platform using Core i7
- Parallel operation of Windows and RTOS VxWorks
- Extension modules for Sercos, PROFINET, EtherNet/IP und PROFIBUS

≥ MLC14


# IndraMotion MLC – Product status



# IndraMotion MLC




- Complete and universal automation system for all Motion Control applications
- Motion Control – efficient Motion kernel for ELS synchronization of up to 64 axes
- Robot Control – Robot kernel for movements in 3D and belt synchronization
- Technology function blocks – toolbox solutions for e.g. packaging, printing and handling
- Motion Control for hydraulic axes























# Functions for Motion Control (selection)

|  |   |  |   |
|--|---|--|---|
|  | <b>Logic control</b><br>according to IEC 61131-3 with extensions  |  | <b>Real master axes</b><br>Encoder axes                       |
|  | <b>PLCopen</b><br>Standardized function blocks for Motion Control |  | <b>Virtual master axes</b>                                    |
|  | <b>AxisInterface</b><br>Easy Motion programming                   |  | <b>Multi-axes synchronization</b><br>Electronic Line Shafting |
|  | <b>GAT</b><br>Template based programming                          |  | <b>Cross communication</b><br>Link axes                       |
|  | <b>Electronic gears</b>   |  | <b>Master axes cascading</b>                                  |
|  | <b>Electronic cams</b>  |  | <b>Positioning</b>  |
|  | <b>FlexProfile</b>  |  | <b>Linear interpolation</b>                                   |

# Technology function blocks (selection)







|  |   |   |  |   |                        |
|--|---|---|--|---|------------------------|
|   | <b>Sag Control</b>  |   | <b>Flying Shear</b>  |  | <b>PID Control</b>     |
|   | <b>Tension Control</b>  |   | <b>Print Mark Registration</b>                               |  | <b>Crank Cinematic</b> |
|   | <b>Cross Cutter</b>   |   | <b>Color Register Control</b>                                |  | <b>Cross Sealing</b>   |
|   | <b>Handling Interpreter for PTP multi-axes coordination</b>   |   | <b>Manual Axis Positioning (Jog) Incremental, continuous</b> |  | <b>CamLock</b>         |
|   | <b>Temperature Control</b>                                    |   | <b>Measuring Wheel</b>                                       |  | <b>Smart Belt</b>      |
|   | <b>High Speed Cam Switches</b>                                |   | <b>Touch Probe</b>   |  | <b>Magic Belt</b>      |
|  | <b>Winder Toolbox Functions for dancer, diameter, tension</b> |  | <b>Two-point Control</b>                                     |   |                        |





# Platform IndraControl L

# Control Portfolio – IndraControl L

|                                 |  |  |  |  |
|---------------------------------|---|--|---|---|
| Platform                        | L25   | L45  | L65   | L75   |
| Drive interface                 | Sercos III  | Sercos III   | Sercos III  | Sercos III  |
| Max. axis number                | 16  | 32   | 64  | 64  |
| Cycle time                      | 2 ms / 1 ms   | 1 ms / 1 ms  | 0.5 / 0.25 ms   | 0.5 / 0.25 ms   |
| Max. number of function modules | 2   | 4  | 4   | 4   |
| Onboard IO                      | <input checked="" type="checkbox"/>   | 8I/8O  | 8I/8O   | 8I/8O   |
| C2C                             | FM Sercos III   | FM Sercos III  | FM Sercos III   | FM Sercos III   |
| EtherNet/IP Scanner/Adapter     | with FM   | <input checked="" type="checkbox"/> / <input checked="" type="checkbox"/>          | <input checked="" type="checkbox"/> / <input checked="" type="checkbox"/>           | <input checked="" type="checkbox"/> / <input checked="" type="checkbox"/>           |
| PROFINET IO Contr./Device       | with FM   | <input checked="" type="checkbox"/> / <input checked="" type="checkbox"/>          | <input checked="" type="checkbox"/> / <input checked="" type="checkbox"/>           | <input checked="" type="checkbox"/> / <input checked="" type="checkbox"/>           |
| PROFIBUS Master/Slave           | with FM   | <input checked="" type="checkbox"/> / <input checked="" type="checkbox"/>          | <input checked="" type="checkbox"/> / <input checked="" type="checkbox"/>           | <input checked="" type="checkbox"/> / <input checked="" type="checkbox"/>           |
| Robot Control                   | <input checked="" type="checkbox"/>   | <input checked="" type="checkbox"/>  | <input checked="" type="checkbox"/>   | <input checked="" type="checkbox"/>   |

# IndraControl L25



# IndraControl L45/L65/L75




## IndraControl Lx5 – Display

- 8-digits display with 4 keys
- Display of diagnosis and status information
- Additional information with regards to hardware and installed firmware:
  - Material number
  - Type code
  - Hardware index
  - Serial number
  - Firmware version
  - etc.
- Network Settings
- Load base parameters




# IndraControl Lx5 – Display



SIDEX

# IndraControl Lx5 – Display



After modification of the network parameters, the network settings can be validated by the command „Apply IP configuration“. As a result the new settings are effective immediately and no restart of the control is required!

# IndraControl Lx5 – Display


|             |                  |                    |
|-------------|------------------|--------------------|
| Device Info | Firmware         | CML65s-MLC ...     |
|             | OHC Fan:         | 0.49 h             |
|             | OHC Control:     | 395.84 h           |
|             | Temperature:     | + 41.0 C           |
|             | Serial Number:   | SN: 47114712       |
|             | Index:           | 313                |
|             | Type Code:       | CML65.1-3P-504 ... |
|             | Material number: | R911170899         |




- Enter
- Esc
- Down
- Up



# IndraControl Lx5 – Display




# IndraControl Lx5 – Display



## IndraControl Lx5 – Load Base Parameters

- During the boot sequence (after display of „BOOT1.01“) press the keys **Esc** and **Enter** simultaneously (keep pressed!) until „BOOTSTOP“ is displayed:




- Press keys **↓** and **↑** simultaneously and confirm by pressing the key **Enter**



- As a result all data on the control is cleared and the control reboots!

# IndraControl Lx5 – Bootstop Menu





# Platform IndraControl XM

# Control Portfolio – New Platforms


|                                 |  |  |  |
|---------------------------------|---|---|---|
| Platform                        | XM21  | XM22  | IPC   |
| Drive interface                 | Sercos III  | Sercos III  | Sercos III (EM)   |
| Max. axis number                | 40  | 32  | 99  |
| Cycle time                      | 2 ms / 1 ms   | 1 ms / 0,25 ms  | 0.5 ms / 0.25 ms  |
| Max. number of function modules | 3   | 3   | 4   |
| Onboard IO                      | ☒   | ☒   | ☒   |
| C2C                             | EM Sercos III   | EM Sercos III   | EM Sercos III   |
| EtherNet/IP Scanner/Adapter     | with EM   | with EM   | with EM   |
| PROFINET IO Contr./Device       | with EM   | with EM   | with EM   |
| PROFIBUS Master/Slave           | with EM   | with EM   | with EM   |
| Robot Control                   | ☑   | ☑   | ☑   |

# IndraControl XM2 – Technical data

- Processor:
  - XM21: E620T 600 MHz
  - XM22: E660T 1300 MHz
- Main memory: 512 MB RAM
- Flash (internal): 1GB
- Retain memory: 64 kByte (PLC)  
64 kByte (Motion)
- Performance:
  - XM21: ≈ CML45
  - XM22: ≈ CML65




# IndraControl XM2 – Interfaces & operating elements





# IndraControl XM21/22 – Diagnosis LEDs




## IndraControl XM2 – Delivery status

- Out-of-the-box there is only an **initial firmware** on the control
- The system firmware has to be downloaded to the control during the commissioning
- This can be achieved either with the web-based tool **FirstTouch** or from **IndraWorks**
- Standard IP address: **192.168.1.1**
- Restoration of the delivery status, or recovery of the default network settings can be done via switches SF1 and SF2





# IndraControl XM2 – Delivery status

- LEDs **DIA3** and **DIA4** *blinking red* (alternating)  
→ Initial firmware is active
- LED **E** permanently **green**  
→ Web-Server for FirstTouch is active
- ☞ Use of FirstTouch to adjust the network settings
- ☞ Download of system firmware with FirstTouch or from IndraWorks



- Press button SF2 > 5 seconds
- LEDs **DIA3** and **DIA4** *blinking red* (alternating)  
→ Initial firmware is active
- LED **E** permanently **red**  
→ Menu is active
- ☞ Reset network parameters
- ☞ Reset Username & password
- ☞ Restore delivery status



# IndraControl XM2 – First Touch



Enter IP address of IndraControl XM

User: boschrexroth  
Password: boschrexroth

Login

Enter IP address of IndraControl XM and login with user ***boschrexroth*** plus password ***boschrexroth***!

# IndraControl XM2 – First Touch

**IndraControl First Touch** Rexroth Bosch Group

Welcome Hardware Network Firmware File Manager Logout

**Hardware Info**

| Material Index | Type Code               | Serial Number | Model Number |
|----------------|-------------------------|---------------|--------------|
| AA1            | IM200 01-01-31-31-___NH | 726140206158  | PO...48      |

**File Transfer**

| Name   | Modified          | Size        | Delete |
|--------|-------------------|-------------|--------|
| ROOT   |                   |             |        |
| INTFW  | 01-Jan-2013 13:00 | [PARTITION] | ⊞      |
| OEM    | 01-Jan-2013 13:00 | [PARTITION] | ⊞      |
| SYSTEM | 01-Jan-2013 13:00 | [PARTITION] | ⊞      |
| USER   | 01-Jan-2013 13:00 | [PARTITION] | ⊞      |

**Network Settings**

IP-Address: 192.168.1.1  
Gateway: 192.168.1.1  
Subnet Mask: 255.255.0.0  
Write Configuration

**Firmware Management**

System Firmware

Note: Control is in Initial Mode. Select drop-down menu for available functions. Version of initial Firmware: R011341916-FW0L-IM2100\_INT\_...-01V0P\_... (1.6.0.0)

# IndraControl XM2 – FirstTouch

IndraControl First Touch

Rexroth Bosch Group

Welcome Hardware Network **Firmware** File Manager Core Dump Logout

### Firmware Management

#### System Firmware


Status: Control is in **Initial Mode**. Select drop down menu for available functions. Version of Initial Firmware: R911341916 FWL-XM2100\_INIT-01V08- (1.8.0.0)

|          |                           |         |
|----------|---------------------------|---------|
| Firmware | XM2sss-MLC-14V10.0467.005 | Actions |
|----------|---------------------------|---------|


- Firmware download
- Restore Factory Settings
- Reboot to initial mode (initial firmware active)

- Update System Firmware
- Reboot into System Mode
- Backup System Firmware
- Factory Reset
- Reboot Initial Mode


# IndraControl XM2 – Menu of initial firmware




**Start FirstTouch**



**Restore default network settings**




**Clear username and password**




**Restore factory settings**

# IndraControl XM2 – Restore Factory Settings





# IndraControl XM2 – Scalable Firmware



# IndraControl XM2 – Functional Packages

| Functional package | Name                       | Description   | Prerequisites |
|--------------------|----------------------------|---|---------------|
| PLC                | Programmable Logic Control | PLC runtime system compliant to IEC 61131 (IndraLogic 2G)                           | -             |
| MOT                | Motion                     | Single axis movements and synchronized operation motion of several axes             | PLC           |
| TEC                | Technology                 | PLC function blocks for multiple technology functions                               | PLC, MOT      |
| ROCO               | Robot Control              | Kinematics (Scara, Delta, Cartesian, ...) and axis transformation for robot control | PLC, MOT      |
| HYD                | Hydraulics                 | Centralized control for hydraulic axes  | PLC, MOT      |
| OPC UA             | OPC UA                     | OPC UA server in IndraMotion MLC  | PLC           |
| OCI                | Open Core Interface        | API for high level language programming   | PLC           |

# IndraControl XM2 – Functional Packages




Fig.: Type code

## Configurable features

- CPU variety
  - XM21 or XM22
- Extensibility with extension modules
  - Bus socket module
- Range of firmware functions
  - Functional packages

Each configuration has a unique material number and type code

\* Example for a feasible configuration



# Agenda


- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information

# IndraWorks – Supported operation systems




# Agenda

- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information






# Engineering Workflow




# Engineering with IndraWorks

Selection of devices by drag & drop



Parameterization through wizards



Automatic generation of program data

Control parameters



Drive parameters



IndraLogic elements

```

(* Automated generated code by X2C/MLC *)
(* Please don't edit, the code will be overwritten. For users
(attribute 'linkways')
VAR_GLOBAL CONSTANT

(**Real axis "Axis1" with axis number 1*)
Axis1: AXIS_REF :=(CtrlNo:=LOCAL_CTRL,AxisNo:=AXIS_1);

(**Real axis "Axis2" with axis number 2*)
Axis2: AXIS_REF :=(CtrlNo:=LOCAL_CTRL,AxisNo:=AXIS_2);
    
```

# Parameterization through wizards

Enter device name

Comment  
(tooltip in project explorer)

User name can be modified

Push "Next" button

# Parameterization through wizards

Insert IndraMotion MLC XM2

**Step 2: Hardware/Communication**  
Select the device configuration and specify the communication settings.

Device configuration

Device type: IndraMotion MLC XM2    XM2s00.01-01

Firmware version: MLC14VRS

Firmware release: FWA-XM2sss-MLC-14V10

Ethernet communication

IP address: 192.168.1.1

PLC gateway: localhost

PLC communication:  TCP     UDP

Connection test:

Communication test to control successful:  
Firmware: XM2sss-MLC-14V10.0467.005  
Device name: Control name  
Author: --

PLC communication successful:  
Address: 192.168.1.1

Execute

<< Back    Next >>    Cancel    Help

Select appropriate firmware version


Enter IP address

Execute Connection Test

Connection Test OK!

Push "Next" button

# Parameterization through wizards



Activate or deactivate Secure online mode

Check of array indexes at runtime of PLC program

Download PLC sources (for Online compare)

Select favorite IEC language

GAT Wizard offers different templates

Push "Next" button

# Parameterization through wizards

Insert IndraMotion MLC XM2

**Step 4: PLC Application**  
Please select a sample project or a template.  
To extend the functional scope, select different plug-ins.

Sample projects

- AxisInterface**  
Sample project explaining the use of the AxisInterface
- GAT compact**  
Sample project for ordinary non-modular machine concepts

Templates

- GAT (central state machine)**  
Template for modular machines with central state machine and state coupling of the modules
- GAT (decentral state machine)**  
Template for modular machines with decentral state machine without state coupling of the modules

**User-defined GAT**  
Imports the selected GAT folder iwx file. The GAT libraries and tasks are added

Plugins

- AxisInterface Extended
- Kinematics Interface
- Sercos Diagnosis
- HydraulicBasic
- MlcTrending
- Profibus Diagnosis

Navigation: << Back, **Next >>**, Cancel, Help

Sample projects  
AxisInterface or GAT<sup>compact</sup>

Template  
GAT<sup>central</sup> or GAT<sup>decentral</sup>

User-defined GAT or  
OMAC PackML


Select appropriate  
Plugins

Push "Next" button

# Parameterization through wizards

Insert IndraMotion MLC XM2

**Step 5: Function packages**  
Select the required function packages.

 When using a non-licensed function, Bosch Rexroth does not assume any warranty! Non-licensed function packages can only be used for test purposes for a limited time. Purchase a full license (see Function Description), in case of permanent use of the function package!

Order the license of the function packages at Bosch Rexroth.

| Function package   | Material number | Type Code                      |
|--|-----------------|--------------------------------|
| <input checked="" type="checkbox"/> Programmable Logic Control | R911342837      | FWS-XM2100-MLC-NNVRS-NN-PLC-00 |
| <input checked="" type="checkbox"/> IM Motion                  | R911344243      | FWS-XM2200-MLC-NNVRS-NN-PLC-00 |
| <input checked="" type="checkbox"/> IM Technology              |                 |                                |
| <input type="checkbox"/> Robot Control                         |                 |                                |
| <input type="checkbox"/> Hydraulics                            |                 |                                |
| <input checked="" type="checkbox"/> OPC UA                     |                 |                                |
| <input checked="" type="checkbox"/> Open Core Interface        |                 |                                |

Description:  
PLC runtime according to IEC 61131-3 3rd Edition

<< Back   **Next >>**   Cancel   Help


Select appropriate Function package

Required license for selected Function package

Description of selected Function package

Push "Next" button

# Parameterization through wizards



Enable or disable Sercos

Enable or disable EtherNet/IP adapter

Up to 3 Extension modules

Press "Finish" button to add MLC to project



# MLC Firmware Management

The screenshot displays the IndraWorks software interface. On the left, the 'Project Explorer' shows a tree view with 'MLC L25' selected. A context menu is open over 'MLC L25', with 'Firmware Management...' highlighted. On the right, the 'Firmware Management' window is open, showing device details for 'MLC\_L25' (IP: 192.168.1.1). It lists 'Firmware available for download' and 'Current firmware in device'. A table below lists various firmware files with their names, change dates, types, and sizes.

| Name                         | Änderungsdatum   | Typ      | Größe     |
|------------------------------|------------------|----------|-----------|
| CML25s-MLs-12V12.0458.004.fw | 27.10.2014 18:16 | FW-Datei | 8.046 KB  |
| CML25s-MLs-13V22.0660.fw     | 09.10.2015 16:31 | FW-Datei | 12.735 KB |
| CML25s-MLs-14V10.0467.005.fw | 23.11.2015 15:19 | FW-Datei | 13.409 KB |
| CML25s-XLs-12V12.0458.004.fw | 27.10.2014 18:16 | FW-Datei | 8.046 KB  |
| CML25s-XLs-13V22.0660.fw     | 09.10.2015 16:32 | FW-Datei | 12.735 KB |
| CML25s-XLs-14V10.0467.005.fw | 23.11.2015 15:22 | FW-Datei | 13.409 KB |
| CML45s-MLs-12V12.0458.004.fw | 27.10.2014 18:16 | FW-Datei | 7.681 KB  |
| CML45s-MLs-13V22.0660.fw     | 09.10.2015 16:32 | FW-Datei | 12.584 KB |
| CML45s-MLs-14V10.0467.005.fw | 23.11.2015 15:19 | FW-Datei | 13.243 KB |
| CML45s-MLs-12V12.0458.004.fw | 27.10.2014 18:16 | FW-Datei | 7.681 KB  |
| CML45s-XLs-13V22.0660.fw     | 09.10.2015 16:32 | FW-Datei | 12.584 KB |
| CML45s-XLs-14V10.0467.005.fw | 23.11.2015 15:22 | FW-Datei | 13.243 KB |
| CML65s-MLs-12V12.0458.004.fw | 27.10.2014 18:16 | FW-Datei | 7.681 KB  |

Firmware files are located in the folder  
**C:\Program Files (x86)**  
**... \Rexroth\IndraWorks\MLC\Firmware**

# MLC Firmware Management

Firmware Management

Device: MLC\_L25  
IP address: 192.168.1.1

Firmware available for download:

- CML25s-MLs-12V12.0458.004.fw
- CML25s-MLs-13V22.0660.fw
- CML25s-MLs-14V10.0467.005.fw

Current firmware in device:

- CML25s-MLC-13V14.0604.003

Download...

Firmware management

⚠ Please ensure that no other applications are communicating with the device during the firmware download! The power supply and the connection to the device cannot be interrupted during the download!

Current firmware in device: CML25s-MLC-13V14.0604.003  
Firmware selected for download: CML25s-MLs-14V10.0467.005.fw

Execute firmware download?

Ja Nein

Downloading...

Download (51%)


Downloading...

Reboot (92%)

Downloading...

Resuming the communication (93%)

# MLC Firmware Management



# MLC Firmware Management

The image displays three sequential screenshots of the 'Firmware Management' application window, illustrating the process of installing a new firmware version.

- Left Screenshot:** Shows the initial state. Under 'Control information', the 'Firmware' field indicates 'No system firmware is active'. In the 'Firmware selection' section, 'Firmware of installation' is selected, and the file '14V10: XM2sss-MLC-14V10.0467.005.fw' is listed. The 'Installation' section shows a list of steps: 1. Preparation, 2. File transfer, 3. Installation, 4. Restart, and 5. Verification. The 'Download' button is highlighted with a blue callout box containing the text 'Press "Download"'. A large red 'DRAFT' watermark is overlaid on the center of the image.
- Middle Screenshot:** Shows the progress of the installation. The 'File transfer' step (2) is highlighted with a green progress bar, and a blue callout box labeled 'Progress indicator' points to it. The 'Download' button is now disabled.
- Right Screenshot:** Shows the installation is complete. All five steps (1. Preparation, 2. File transfer, 3. Installation, 4. Restart, 5. Verification) are marked with green checkmarks. A blue callout box labeled 'Download complete!' points to the 'Download' button, which is now disabled.

# Scanning of Sercos Devices

Project Explorer

- XM
  - General Module Folder
    - MLC\_XM22
      - Logic
      - Motion
        - Real axes
        - Virtual axes
        - Encoder axes
        - Controller axes
      - Technology
        - S20\_I/O
          - Sercos

Context Menu:

- Open
- Add
- Set device
- Parameters
- Bus address overview...
- Scan Bus Configuration
- Sercos configuration
- Firmware Management...

Scan Bus Configuration - MLC\_XM22

| Addr. | Device Name   | Axis Name | No. | Device Identification   | Ipo Drive                           |
|-------|---|-----------|-----|---|-------------------------------------|
| 1     | Drive1  | Drive1    | 1   | FWA-INDRV-MPB-18VRS-D5  | <input checked="" type="checkbox"/> |
| 65    | R_ILB_S3_AI12_AO...   |           | 65  | R911171949 (Bosch Rexroth...)                                 |                                     |
| 66    | S20_S3_BK_ <ul style="list-style-type: none"> <li>S20_SSDI_8_4</li> <li>S20_SSDO_8_3</li> </ul> |           | 66  | R911173318 (Bosch Rexroth...)<br>S20-SSDI-8/4<br>S20-SSDO-8/3 |                                     |

Add Devices

# Scanning of Sercos Devices

**Sercos devices in project**

| Addr. | Device Name         | Axis Name | No. | Device Identification         | Ipo Drive                           | Closed Loop                         | Exp.-packa... |
|-------|---------------------|-----------|-----|-------------------------------|-------------------------------------|-------------------------------------|---------------|
| 1     | Drive1              | Drive1    | 1   | FWA-INDRV*-MPB-18VRS-D5       | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | SNC           |
| 65    | R_ILB_S3_AI12_AO... |           | 65  | R911171949 (Bosch Rexroth...) |                                     |                                     |               |
| 66    | S20_S3_BK_          |           | 66  | R911173318 (Bosch Rexroth...) |                                     |                                     |               |
|       | ..... S20_SSDI_8_4  |           |     | S20-SSDI-8/4                  |                                     |                                     |               |
|       | ..... S20_SSDO_8_3  |           |     | S20-SSDO-8/3                  |                                     |                                     |               |

**Detected Sercos devices**

| Addr. | Device Identification         | Extended Identification          | Topol... |
|-------|-------------------------------|----------------------------------|----------|
| 1     | HCS0x (Bosch Rexroth AG)      | FWA-INDRV*-MPB-18V18-D5-1-SNC-NN | 1        |
| 65    | R911171949 (Bosch Rexroth...) | R-ILB S3 AI12 AO4 SSH-IN4        | 2        |
| 66    | R911173318 (Bosch Rexroth...) | S20-S3-BK+                       | 3        |
| ..... | R911173191                    | S20-SSDI-8/4                     |          |
| ..... | R911173192                    | S20-SSDO-8/3                     |          |

**Add Devices**

Only show newly scanned devices    **Scan**    **Apply Addresses**

**Close**    **Help**

With "Add Devices" all selected devices will be added to the project

# Scanning of Sercos Devices



Scan Bus Configuration - MLC\_XM22

| Project |       |                     |           |     |                               |           | Control     |               |       |                               |                                  |          |
|---------|-------|---------------------|-----------|-----|-------------------------------|-----------|-------------|---------------|-------|-------------------------------|----------------------------------|----------|
| ✓       | Addr. | Device Name         | Axis Name | No. | Device Identification         | Ipo Drive | Closed Loop | Exp.-packa... | Addr. | Device Identification         | Extended Identification          | Topol... |
| ✓       | 1     | Axis1               | Axis1     | 1   | FWA-INDRV*-MPB-18VRS-D5       | ✓         | ✓           | SNC           | 1     | HCS0x (Bosch Rexroth AG)      | FWA-INDRV*-MPB-18V18-D5-1-SNC-NN | 1        |
| ✓       | 65    | R_ILB_S3_AI12_AO... |           | 65  | R911171949 (Bosch Rexroth...) |           |             |               | 65    | R911171949 (Bosch Rexroth...) | R-ILB_S3 AI12 AO4 SSI-IN4        | 2        |
| ✓       | 66    | S20_S3_BK_          |           | 66  | R911173318 (Bosch Rexroth...) |           |             |               | 66    | R911173318 (Bosch Rexroth...) | S20-S3-BK+                       | 3        |
|         |       | S20_SSDI_8_4        |           |     | S20-SSDI-8/4                  |           |             |               |       | R911173191                    | S20-SSDI-8/4                     |          |
|         |       | S20_SSDO_8_3        |           |     | S20-SSDO-8/3                  |           |             |               |       | R911173192                    | S20-SSDO-8/3                     |          |

Only show newly scanned devices

Axis name  
 Axis number  
 IPO drive / control  
 Functional package  
 Sercos Address  
 Firmware / Identification

# Scanning of Sercos Devices



„Identify device visually“ results in a flashing at the IndraDrive or the IO node



# Remote Address Assignment


Scan Bus Configuration - MLC\_XM22

| Project |       |                     |           |     |                               |           |             | Control       |       |                               |                                  |          |
|---------|-------|---------------------|-----------|-----|-------------------------------|-----------|-------------|---------------|-------|-------------------------------|----------------------------------|----------|
| ✓       | Addr. | Device Name         | Axis Name | No. | Device Identification         | Ipo Drive | Closed Loop | Exp.-packa... | Addr. | Device Identification         | Extended Identification          | Topol... |
| ✓       | 1     | Axis1               | Axis1     | 1   | FWA-INDRV*-MPB-18VRS-D5       | ✓         | ✓           | SNC           | 10    | HCS0x (Bosch Rexroth AG)      | FWA-INDRV*-MPB-18V18-D5-1-SNC-NN | 1        |
| ✓       | 65    | R_ILB_S3_AI12_AO... |           | 65  | R911171949 (Bosch Rexroth...) |           |             |               | 65    | R911171949 (Bosch Rexroth...) | R-ILB S3 AI12 AO4 SSI-IN4        | 2        |
| ✓       | 66    | S20_S3_BK_          |           | 66  | R911173318 (Bosch Rexroth...) |           |             |               | 65    | R911173318 (Bosch Rexroth...) | S20-S3-BK+                       | 3        |
|         |       | S20_SSDI_8_4        |           |     | S20-SSDI-8/4                  |           |             |               |       | R911173191                    | S20-SSDI-8/4                     |          |
|         |       | S20_SSDO_8_3        |           |     | S20-SSDO-8/3                  |           |             |               |       | R911173192                    | S20-SSDO-8/3                     |          |

Only show newly scanned devices    Scan    Apply Addresses    Close    Help

Modified Sercos address    Address assignment

# Scanning of Sercos Devices



Drives are added to the Real Axes folder (logical view)

Drives are added to the Sercos folder (physical view)

Sercos IOs also are added to the Sercos folder

Modular Sercos slaves are added including additional modules


# Remote address assignment

- Why?
  - Address assignment for devices without address switch (e.g. Sercos IO modules)
  - Better usability by centralized assignment from IndraWorks
  
- The topology address corresponds to the position in the ring
- Visualization of all devices in ascending order in a table form
- The Sercos address can be modified



| Topology Address | 1 | 2 | 3 | 4 | 5  |
|------------------|---|---|---|---|----|
| Sercos Address   | 1 | 3 | 2 | 4 | 20 |

# Remote address assignment





# Remote address assignment

The screenshot shows the 'Control configuration' window for MLC\_XM22. It features a table with columns for Name, Address, Type, Device Identification, Extended Identification, Status, Address, Top. Addr., Type, and Device Identificat. The table contains three rows of data. A callout box points to the 'Status' column of the second row, which contains a green checkmark. A large red 'SIDEX' watermark is overlaid on the image.

| Name                      | Address | Type | Device Identification                | Extended Identification | Status | Address | Top. Addr. | Type | Device Identificat |
|---------------------------|---------|------|--------------------------------------|-------------------------|--------|---------|------------|------|--------------------|
| Axis1                     | 1       |      | FWA-INDRV*-MPB-18 (Bosch Rexroth AG) | FWA-INDRV*-MPB-18       |        | 1       | 1          |      | HCS0x (Bosch Re    |
| R_ILB_S3_AI12_AO4_SSI_IN4 | 65      |      | R911171949 (Bosch Rexroth AG)        |                         |        | 65      | 2          |      | R911171949 (Bos    |
| S20_S3_BK_                | 66      |      | R911173318 (Bosch Rexroth AG)        |                         |        | 66      | 3          |      | R911173318 (Bos    |

Buttons at the bottom: Adjust Axis Activation, Assign Addresses, Scan.

Callout: New setting is effective!

# Sercos Configuration


## New handling of Sercos Configuration with MLC14

- Motion devices are applied to the control while downloading the Motion configuration
- PLC devices are applied to the control upon login
- If the control detects a misconfiguration, it is reported via the error/diagnostic memory
- In addition, the dialog "Sercos Configuration" displays, whether the configuration matches the connected devices as well as the differences

# IndraWorks – Tool Bars



Switch Online/Offline,  
Create archive or Restore archive




Create/Open/Close/Save project,  
Undo etc.




MLC Device Status/Warnings/Errors,  
Clear Errors



IndraLogic Login / Logoff, Start / Stopp etc.




Parameter Editor, Parameter Groups,  
IDN search




Switch Sercos Phase



# IndraWorks – Tool Bars



# IndraWorks – Add virtual axis



# IndraWorks – Edit, Duplicate, Add, Remove axis

Axis Overview Motion

Axes can be edited, duplicated, added or removed in this dialog.  
All changes are only applied after confirming with "OK".

| Axis Name | Comment | Author    | Type         | No. | Firmw |
|-----------|---------|-----------|--------------|-----|-------|
| Axis1     |         | Joachi... | Real axis    | 1   | FWA-  |
| vAxis2    |         | Joachi... | Virtual axis | 2   |       |

Total: 2 axes

# IndraWorks – Edit, Duplicate, Add, Remove axis

- Axis Overview displays all axes of the system
- Axis characteristics can be modified
- Axis can be duplicated, added or removed

Add, duplicate or remove an axis

Axis Overview Motion

Axes can be edited, duplicated, added or removed in this dialog.  
All changes are only applied after confirming with "OK".


0 errors 0 warnings

| Axis Name | Comment | Author    | Type         | No. | Firmware                | Addr. | Drive | Ipo Drive                           | CL                                  | Exp.-pack... | Controller Type |
|-----------|---------|-----------|--------------|-----|-------------------------|-------|-------|-------------------------------------|-------------------------------------|--------------|-----------------|
| Axis1     |         | Joachi... | Real axis    | 1   | FWA-INDRV*-MPB-18VRS-D5 | 1     | Axis1 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | SNC          |                 |
| vAxis2    |         | Joachi... | Virtual axis | 2   |                         |       |       |                                     |                                     |              |                 |


Total: 2 axes

OK Cancel Apply


# IndraWorks – Project Explorer



# IndraWorks – Registers in Project Explorer



# IndraWorks – Switching Online




A comment “Partially synchronized” is displayed at the control. This indicates that the project configuration differs from the configuration inside the control!

As long as the configuration doesn't match no access to the drive dialogues is possible!

SIDEX

# IndraWorks – Download of Motion Configuration



Download of motion configuration

Comparison of motion configuration is always possible!



# IndraWorks – Motion Configuration

Motion Configuration Comparison - MLC\_XM22

| Project (MLC_XM22 [P2, Partially synchronized]) | Status | Device       |
|---|--------|--------------|
| MLC_XM22  | x      | Control_name |
| IM Motion                                       | x      |              |
| Real axes                                       | x      |              |
| 1 - Axis1                                       | x      |              |
| Virtual axes                                    | x      |              |
| 2 - vAxis2                                      | x      |              |
| Encoder axes                                    | x      |              |
| Controller axes                                 | x      |              |
| Sercos  | x      | Sercos       |

Motion Configuration in project

Motion Configuration on control


x mismatch between project and Motion Configuration on control

8 Difference(s) 4:44:36 PM

# Using the IP channel in Sercos (1)


- IP communication with devices in the Sercos link
- Required parameters
  - IP settings Engineering port
  - SERCOS addresses of drives and IO
- Automatic setting of all IP addresses for all IndraDrives
- ... and further network settings of IndraDrives

SIDEX




# Using the IP channel in Sercos (2)



- Sercos interfaces of MLC are “bridged”
- Bridging means that different physical networks are combined into one logical network
- Common IP address range for all Sercos interfaces of MLC
- All drives and IOs in the Sercos drive link are accessible via Engineering port
- ... and also remote MLCs in the Sercos C2C link



# Using the IP channel in Sercos (3)



# IndraWorks –Initial commissioning assistant



Guided axis commissioning in 14 steps!

# Axes commissioning without PLC

The screenshot shows the 'Project Explorer' on the left with the 'Motion' folder expanded. The 'Axis commissioning' option is highlighted with a blue arrow. A large red 'S' watermark is overlaid on the image.

The 'Dangerous Motions' dialog box contains the following text:

**WARNING !**

**Dangerous motions!**  
 Danger to life, severe bodily harm or material damage.

**Before commissioning:**

- Position Emergency Stop button readily accessible and in immediate vicinity
- Ensure that the Emergency Stop button is working

**By clicking on OK, I hereby confirm that I have thoroughly read the safety instructions.**

**Measures:**

- Position Emergency Stop button easily accessibly and in immediate vicinity. Verify if the Emergency Stop button is working.
- Set the drives to standstill before accessing the hazard area and protect it against unintentional start-up, e.g. by activating the power connection of the drives via the Emergency Stop circuit or by using a safe interlock.

Buttons: OK, Cancel

# Axes commissioning without PLC

Axis commissioning - MLC\_XM22

MLC\_XM22

| Axis Name | Axis No. | Position    | Velocity     | Torque | Interpol. Pos. | Interpol. Velocity | Extended Axis Status |
|-----------|----------|-------------|--------------|--------|----------------|--------------------|----------------------|
| Axis1     | 1        | 339.80 Grad | 100.71 U/min | 4.60 % | 346.30 Grad    | 100.00 U/min       | Axis is in 'C'       |
| vAxis2    | 2        | 352.06 Grad | 100.00 U/min |        | 356.86 Grad    | 100.00 U/min       | Axis is in 'C'       |

Commands:

Axis status: Command velocity reached, Drive with torque

Velocity Control | Positioning | Velocity Synchronization | Position Synchronization | Phase Offset | FlexProfile | Stop

Start

Velocity:  U/min

Acceleration:  rad/s<sup>2</sup>

Deceleration:  rad/s<sup>2</sup>


Jerk:  rad/s<sup>3</sup>

Jog:    U/min




Axes can be moved in any operating mode independent of the PLC program!

# Consistent IO configuration






# IO configuration – Inline IOs



Add appropriate Inline modules to the node Inline IO

Drag & Drop




The IO configuration in IndraWorks is uniform. The configuration of PROFIBUS IOs and Sercos IOs follows the same philosophy.

Open **Periphery** in Device Library  
Select category **Inline**

# IO configuration – PLC Addresses

- PLC addresses are assigned automatically when peripheral devices are added
- The syntax according to IEC 61131 is as follows:




# IO configuration – PLC Addresses

- Examples:

| % | Memory Area Prefix | Size Prefix | Number | . | Number |                        |
|---|--------------------|-------------|--------|---|--------|------------------------|
| % | I                  | X           | 100    | . | 3      | Input bit 100.3        |
| % | Q                  | X           | 110    | . | 7      | Output bit 110.7       |
| % | I                  | B           | 5      |   |        | Input byte 5           |
| % | M                  | W           | 810    |   |        | Marker word 810        |
| % | M                  | W           | 812    |   |        | Marker word 812        |
| % | Q                  | D           | 200    |   |        | Output double word 200 |

# IO configuration – Address assignment & Mapping



**S20\_DO\_16\_3**

Benutzerdefinierte Parameter E/A-Abbild Information

Kanäle

| Variable       | Mapping | Kanal        | Adresse | Typ  | Standa... | Einhe |
|----------------|---------|--------------|---------|------|-----------|-------|
| Digital Output |         |              |         |      |           |       |
|                |         | Digital O... | %QB0    |      |           |       |
|                |         | Digital O... | %QB0    | BYTE |           |       |
|                |         | 00           | %QX0.0  | BOOL | FALSE     |       |
|                |         | 01           | %QX0.1  | BOOL | FALSE     |       |
|                |         | 02           | %QX0.2  | BOOL | FALSE     |       |
|                |         | 03           | %QX0.3  | BOOL | FALSE     |       |

PLC addresses are assigned automatically to new elements

# IO configuration – Address assignment & Mapping

## Mapping to an existing variable

The screenshot shows the 'Kanäle' configuration window for 'S20\_DO\_16\_3'. A table lists the mapping of digital outputs to variables:

| Variable     | Mapping | Kanal | Adresse | Typ  |
|--------------|---------|-------|---------|------|
| Digital O... |         |       | %QB0    |      |
| Digital O... |         |       | %QB0    | BYTE |
|              |         | 01    | %QX0.1  | BOOL |
|              |         | 02    | %QX0.2  | BOOL |

The 'Eingabehilfe' dialog box is open, showing a search for 'bLampe' in the 'Variablen' list. The search results show a variable named 'bLampe' of type 'BOOL'.

## Create a new variable

The screenshot shows the 'Kanäle' configuration window for 'S20\_DO\_16\_3'. A table lists the mapping of digital outputs to variables:

| Variable           | Mapping | Kanal | Adresse | Typ  | Standa... | Ein |
|--------------------|---------|-------|---------|------|-----------|-----|
| Digital O...       |         |       | %QB0    |      |           |     |
| Digital O...       |         |       | %QB0    | BYTE |           |     |
| Application.bLampe |         | 00    | %QX0.0  | BOOL | FALSE     |     |
| bLED2              |         | 01    | %QX0.1  | BOOL | FALSE     |     |
| bLED3              |         | 02    | %QX0.2  | BOOL | FALSE     |     |
| Application        |         | 03    | %QX0.3  | BOOL | FALSE     |     |

An arrow points to the 'Application.bLampe' entry with the text 'Enter variable name'.

# IO configuration – Symbolic access to the IOs

```

1  VAR_GLOBAL
2  // Bitadressen
3  bSwitch_0 AT %IX4.0 : BOOL ; // Switch 0
4  bSwitch_1 AT %IX4.1 : BOOL ; // Switch 1
5  bSwitch_2 AT %IX4.2 : BOOL ; // Switch 2
6  bSwitch_3 AT %IX4.3 : BOOL ; // Switch 3
7  bSwitch_4 AT %IX4.4 : BOOL ; // Switch 4
8  bSwitch_5 AT %IX4.5 : BOOL ; // Switch 5
9  bSwitch_6 AT %IX4.6 : BOOL ; // Switch 6
10 bSwitch_7 AT %IX4.7 : BOOL ; // Switch 7
11
12 bSwitch_8 AT %IX5.0 : BOOL ; // Switch 8
13 bSwitch_9 AT %IX5.1 : BOOL ; // Switch 9
14 bSwitch_10 AT %IX5.2 : BOOL ; // Switch 10
15 bSwitch_11 AT %IX5.3 : BOOL ; // Switch 11
16 bSwitch_12 AT %IX5.4 : BOOL ; // Switch 12
17 bSwitch_13 AT %IX5.5 : BOOL ; // Switch 13
18 bSwitch_14 AT %IX5.6 : BOOL ; //
19 bSwitch_15 AT %IX5.7 : BOOL ; //
20
21 // Byte addresses
22 byS0_S7 AT %IB4 : BYTE ; //
23 byS8_S15 AT %IB5 : BYTE ; //
24
25 // Word addresses
26 wS0_S15 AT %IW4 : WORD ; //
27
28 // Double word addresses
29 dwS0_S31 AT %ID4 : DWORD ; //
30
31 // Long word addresses
32 dwS0_S63 AT %IL4 : LWORD ; //
33 END_VAR
    
```

Variables can be mapped to IOs in IndraLogic using the keyword AT followed by the PLC address


```

VAR_GLOBAL
// Single comment line
(* Bit addresses *)
bValve_0 AT %QX4.0 : BOOL ; // Valve 0
bValve_1 AT %QX4.1 : BOOL ; // Valve 1
bValve_2 AT %QX4.2 : BOOL ; // Valve 2
bValve_3 AT %QX4.3 : BOOL ; // Valve 3
bValve_4 AT %QX4.4 : BOOL ; // Valve 4
bValve_5 AT %QX4.5 : BOOL ; // Valve 5
bValve_6 AT %QX4.6 : BOOL ; // Valve 6
bValve_7 AT %QX4.7 : BOOL ; // Valve 7)
bValve_8 AT %QX5.0 : BOOL ; // Valve 8
    
```

## Agenda


- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information

# MLC Parameter System





# MLC Parameter System



**Control parameters**  
 Configuration data of the control (or information)  
 One set of C parameters per IndraMotion MLC

**Kinematics parameters**  
 Configuration data for Robot Control  
 One set of K parameters per Kinematics

**Probe parameters**  
 Configuration data for probes (M001 – M100)

**Oscilloscope parameters**  
 Configuration data for the oscilloscope



**Axis parameters**  
 Configuration data of the axes (or information)  
 Stored on the control

**Standard parameters defined in the Sercos standard**  
 Configuration data of the drive (or information)  
 Stored in the IndraDrive (Flash/MMC/drive display)

**Proprietary parameters in terms of the Sercos standard**  
 Configuration data of the drive (or information)  
 Stored in the IndraDrive (Flash/MMC/drive display)



# MLC Parameter System – Parameter Editor




Invoke the Online Help directly from the Parameter Editor


Multiple instances of the Parameter Editor can be opened. Provides direct access to the parameter system of MLC and the drives.



# MLC Parameter System – Parameter Editor



With IDN search you get all the control and drive parameters in a tree structure and you can browse the parameter system



SIDEX


# MLC Parameter System – Parameter Groups

| Source | IDN        | Name  | #   | Value | Unit               | Comment |
|--------|------------|---|-----|-------|--------------------|---------|
| RA2    | A-0-3020.0 | Master axis velocity, FlexProfile 0                     | 10  |       | 1/min              |         |
| RA2    | MLC_x      | List of master axis sources, FlexProfile 0              | 0   | --    | --                 |         |
| RA2    | RA1        | List of distances, FlexProfile 0                        | 0   | --    | Deg                |         |
| RA2    | RA2        | List of master axis ranges, FlexProfile 0               | 0   | --    | --                 |         |
| RA2    | RA2        | List of master axis ranges units, FlexProfile 0         | 0   | --    | --                 |         |
| RA2    | VA1        | List of motion laws, FlexProfile 0                      | 0   | --    | --                 |         |
| RA2    | VA2        | List of motion step types, FlexProfile 0                | 0   | --    | --                 |         |
| RA2    | A-0-3027.0 | List of slave axis start velocities, FlexProfile 0      | 0   | --    | Rpm                |         |
| RA2    | A-0-3028.0 | List of slave axis start accelerations, FlexProfile 0   | 0   | --    | rad/s <sup>2</sup> |         |
| RA2    | A-0-3029.0 | List of slave axis start jerks, FlexProfile 0           | 0   | --    | rad/s <sup>3</sup> |         |
| RA2    | A-0-3030.0 | List of slave axis end velocities, FlexProfile 0        | 0   | --    | Rpm                |         |
| RA2    | A-0-3031.0 | List of slave axis end accelerations, FlexProfile 0     | 0   | --    | rad/s <sup>2</sup> |         |
| RA2    | A-0-3032.0 | List of slave axis end jerks, FlexProfile 0             | 0   | --    | rad/s <sup>3</sup> |         |
| RA2    | A-0-3033.0 | List of slave axis travelling velocities, FlexProfile 0 | 0   | --    | Rpm                |         |
| RA2    | A-0-3034.0 | List of slave axis limit accelerations, FlexProfile 0   | 0   | --    | rad/s <sup>2</sup> |         |
| RA2    | A-0-3035.0 | List of slave axis limit jerks, FlexProfile 0           | 0   | --    | rad/s <sup>3</sup> |         |
| RA2    | A-0-3036.0 | List of turning point displacements, FlexProfile 0      | 0   | --    | --                 |         |
| RA2    | A-0-2910.0 | Number of motion steps, MotionProfile 0                 | 1   |       | --                 |         |
| RA2    | A-0-2911.0 | Master axis velocity, MotionProfile 0                   | 0.1 |       | 1/min              |         |
| RA2    | A-0-2912.0 | List of master axis initial positions, MotionProfile 0  | 0   | --    | Deg                |         |
| RA2    | A-0-2913.0 | List of motion laws, MotionProfile 0                    | 0   | --    | --                 |         |

Use Parameter groups to group all parameters relating to a specific MLC function, e.g. FlexProfile, MotionProfile, Phase synchronous operation etc.

The axis for which the parameters are displayed can easily be switched!  
For only one entry as shown above ...

# MLC Parameter System – Parameter Groups



... or for all group entries simultaneously!

# MLC Parameter System – Parameter Groups

Parameter group with all parameters relating to **FlexProfile**

| Source | IDN        | Name  | #   | Value | Unit  | Comment |
|--------|------------|---|-----|-------|-------|---------|
| RA2    | A-0-3020.0 | List of master axis velocities, FlexProfile 0           | 10  |       | 1/min |         |
| RA2    | A-0-3021.0 | List of master axis sources, FlexProfile 0              | 0   | --    | --    |         |
| RA2    | A-0-3022.0 | List of distances, FlexProfile 0                        | 0   | --    | Deg   |         |
| RA2    | A-0-3023.0 | List of master axis ranges, FlexProfile 0               | 0   | --    | --    |         |
| RA2    | A-0-3024.0 | List of master axis ranges units, FlexProfile 0         |     |       | --    |         |
| RA2    | A-0-3025.0 | List of motion laws, FlexProfile 0                      |     |       |       |         |
| RA2    | A-0-3026.0 | List of motion step types, FlexProfile 0                |     |       |       |         |
| RA2    | A-0-3027.0 | List of slave axis start velocities, FlexProfile 0      |     |       |       |         |
| RA2    | A-0-3028.0 | List of slave axis start accelerations, FlexProfile 0   |     |       |       |         |
| RA2    | A-0-3029.0 | List of slave axis start jerks, FlexProfile 0           |     |       |       |         |
| RA2    | A-0-3030.0 | List of slave axis end velocities, FlexProfile 0        |     |       |       |         |
| RA2    | A-0-3031.0 | List of slave axis end accelerations, FlexProfile 0     |     |       |       |         |
| RA2    | A-0-3032.0 | List of slave axis end jerks, FlexProfile 0             |     |       |       |         |
| RA2    | A-0-3033.0 | List of slave axis travelling velocities, FlexProfile 0 |     |       |       |         |
| RA2    | A-0-3034.0 | List of slave axis limit accelerations, FlexProfile 0   |     |       |       |         |
| RA2    | A-0-3035.0 | List of slave axis limit jerks, FlexProfile 0           |     |       |       |         |
| RA2    | A-0-3036.0 | List of turning point displacements, FlexProfile 0      |     |       |       |         |
| RA2    | A-0-2910.0 | Number of motion steps, MotionProfile 0                 | 1   |       | --    |         |
| RA2    | A-0-2911.0 | Master axis velocity, MotionProfile 0                   | 0.1 |       | 1/min |         |
| RA2    | A-0-2912.0 | List of master axis initial positions, MotionProfile 0  | 0   | --    | Deg   |         |
| RA2    | A-0-2913.0 | List of motion laws, MotionProfile 0                    | 0   | --    | --    |         |


Group for operation of IndraDrive with **110 Volts**

| Source    | IDN        | Name                          | #      | Value    |
|-----------|------------|-------------------------------|--------|----------|
| RA1 [1] f | P-0-0114.0 | Undervoltage threshold        | 0      |          |
| RA1 [1] f | P-0-0810.0 | Minimum mains crest value     | 226    |          |
| RA1 [1] f | P-0-0118.0 | Power supply, configuration   | 0b0000 |          |
| RA1 [1] f | P-0-0860.0 | Converter configuration       | 0b0000 |          |
| RA1 [1] f | P-0-0300.0 | Digital I/Os, assignment list | 0      | P-0-0860 |
| RA1 [1] f | P-0-0301.0 | Digital I/Os, bit numbers     | 0      | 9        |

Import/Export as well as Load/Save of parameter groups is supported!

## Activate/Deactivate



- The real axis is created in the IndraMotion MLC project
- The "deactivated" status can be assigned via the context menu and is then marked with  in the Project Explorer
- The A parameters can be accessed. The drive must not exist physically
- The drive is always in P0, even if the sercos ring is in P4 (applies for sercos 2)
- Virtual axes and encoder axes cannot be "deactivated"
- If the drive electronics is taken away from the encoder axis by "deactivating" a real axis, it is also marked as "deactivated"


### Usage:

- During the commissioning, only certain drives should be moved. The other drives are configured and also programmed in the PLC program, but they do not yet exist physically.



## Parking Axis



- The real axis is created in the IndraMotion MLC project
- The “parking” property can be assigned via its context menu and is then marked with  in the Project Explorer.
- The drive must exist physically. The motor does not need to exist. The drive command "Parking Axis" is used
- The A parameters as well as S/P parameters are accessible
- The drive follows the sercos phase. No error messages are generated by the drive
- Virtual axes and encoder axes cannot be "parked"

### Usage:

- Prevent drive from generating an error with the transition to P4 without a connected motor

## Command value decoupling



- Available for real axes with interpolation on the control
- Enabled via context menu and marked with
- The axis is subject to the regular PLCopen state machine in case of an active command value decoupling.
- This means that the MC\_Power has to be executed before executing a motion command. This does not cause the drive to be switched to **AF**. The **AB** mode in the drive is not required for the execution of the FB.
- In case of an active command value decoupling, the position command value calculated by the control will still be written cyclically into the parameter S-0-0047. Since the drive is not in **AF**, the command values are not processed.
- The calculated command value of the axis is reflected by parameter A-0-0151 „Interpolated position of the control“.

### Usage:

- Test motion program without axis movements

# Command value decoupling

- The command value decoupling allows the execution of traveling commands without a motion carried out in the drive.
- The command value decoupling is activated via A-0-0024, „Axis state“.
- The previous states
  - 0 - axis activated
  - 1 - axis parked
  - 2 - axis deactivated
- ... were extended by the following states
  - 4 - axis is activated without command value processing in the drive
  - 5 - axis is activated with command value calculation. Drive is parked
  - 6 - axis activated with command value calculation. Drive not conneted

| Axis status | Without command value decoupling | Command value decoupling activated |
|-------------|----------------------------------|------------------------------------|
| Activated   |                                  | γ                                  |
| Parked      | P                                | P                                  |
| Deactivated | ⊘                                | s <sub>0</sub>                     |


## Agenda

- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information

## IEC 61131 – What is it?

- The international standard IEC 61131 was created as a basis for uniform PLC programming, where modern software technology designs are considered
- The standard comprises 7 parts:
  - IEC 61131-1 General overview, definitions
  - IEC 61131-2 Hardware
  - IEC 61131-3 Programming languages
  - IEC 61131-4 User guidelines
  - IEC 61131-5 Messaging service specification
  - IEC 61131-7 Fuzzy logic
  - IEC 61131-8 Technical report
- MLC is a IEC 61131 compliant system, i.e. Motion programming is based on this standard
- All IEC programming languages are supported

# IEC 61131 – Programming languages



# Relation IndraWorks ↔ IndraLogic

The screenshot displays the IndraWorks interface. On the left, the Project Explorer shows a tree structure under 'MLC\_x' with 'Logic' containing 'Application'. Under 'Application', there are folders for 'Global Variables', 'POUs', 'Visualizations', 'MlcVarGlobal', 'UserVarGlobal', 'Library Manager', 'MotionProg (PRG)', 'PlcProg (PRG)', 'Task Configuration', 'PersistenVars', and 'Visualization Manager'. Under 'Motion', there are folders for 'Real Axes' (containing RA1 and RA2), 'Virtual Axes' (containing VA1 and VA2), 'Encoder Axes', 'Link Axes', and 'Controller axes'. On the right, the 'MlcVarGlobal[MLC\_x: Logic: Application]' code editor shows the following code:

```

1 (* Automated generated code by MLC. *)
2 (* Please don't edit, the code will be overwritten. For
3 VAR_GLOBAL CONSTANT
4
5 (*Virtual axis "VA2" with axis number 4*)
6 VA2: AXIS_REF :=(CntriNo:=LOCAL_CNTRL,AxisNo:=AXIS_4);
7
8 (*Virtual axis "VA1" with axis number 3*)
9 VA1: AXIS_REF :=(CntriNo:=LOCAL_CNTRL,AxisNo:=AXIS_3);
10
11 (*Real axis "RA2" with axis number 2*)
12 RA2: AXIS_REF :=(CntriNo:=LOCAL_CNTRL,AxisNo:=AXIS_2);
13
14 (*Real axis "RA1" with axis number 1*)
15 RA1: AXIS_REF :=(CntriNo:=LOCAL_CNTRL,AxisNo:=AXIS_1);
16
17
18 (*Probe 001*)
19 TouchProbe001: TOUCHPROBE_REF :=(CntriNo:=LOCAL_CNTRL,To
20
21 (*Probe 002*)
22 TouchProbe002: TOUCHPROBE_REF :=(CntriNo:=LOCAL_CNTRL,To
23
24 (*Probe 003*)

```

A red box highlights the 'Virtual Axes' folder in the Project Explorer and the corresponding code lines for VA1 and VA2 in the code editor. A lightbulb icon is present in the bottom left of the text box.

- For every axis in IndraWorks a corresponding global variable with the same name is created, which is used as “key” to designate a specific axis
- Consistent use of axis names in IndraWorks and in the motion program

# Relation IndraWorks ↔ IndraLogic

The screenshot displays the IndraWorks software interface. On the left, the 'Project Explorer' shows a project structure for 'Project8'. Under the 'MLC\_x' folder, there is a 'Logic' folder containing an 'Application' folder. The 'Application' folder includes sub-folders like 'Global Variables', 'POUs', 'Visualizations', and 'Task Configuration'. The 'Task Configuration' folder contains 'MotionTask' and 'PlcTask'. Below the 'Application' folder, there is a 'Motion' folder containing 'Real Axes' (RA1, RA2), 'Virtual Axes' (VA1, VA2), and 'Encoder Axes'. On the right, the 'Task Configuration' window is open, showing a table with columns: Task, Status, IEC-Cycle Count, Cycle Count, and Last Cycle Time (µs). The table lists two tasks: 'MotionTask' and 'PlcTask'. A large red 'SIDEX' watermark is overlaid on the image.

| Task       | Status | IEC-Cycle Count | Cycle Count | Last Cycle Time (µs) |
|------------|--------|-----------------|-------------|----------------------|
| MotionTask |        |                 |             |                      |
| PlcTask    |        |                 |             |                      |

Two tasks are created automatically:

**Motion Task:**


- Handling of axes with special requirements, e.g. Winder, Register control, ELS.
- Handling of fast IOs
- Fast error reaction

**PlcTask:**


- Operational sequences of machine
- Operation modes
- Standard IOs



# Relation IndraWorks ↔ IndraLogic






# What is PLCopen?



- Interest group, independent of controller manufacturers and users
- founded in 1992
- Ambition: promotion, development and use of IEC 61131-3 compatible software
- Advantages: cost reduction e. g. for
  - Training,
  - Development,
  - or Service


# PLCopen and Motion Control

- First Library for standardized motion control functions specified in November 2001
- Main subjects:
  - State Machine
  - Function Blocks
  - Directives for use of Function Blocks




SIDEX

# State Diagram – simplified




# Example of a PLCopen Function block



|            | Name           | Type         | Comment <sup>1)</sup>   |
|------------|----------------|--------------|---|
| VAR_IN_OUT | Axis           | AXIS_REF     | Contains information regarding the actual axis                    |
| VAR_INPUT  | Execute        | BOOL         | Starts the motion if there is a rising edge                       |
|            | Velocity       | REAL         | Maximum velocity value (does not necessarily have to be reached). |
|            | Acceleration   | REAL         | Acceleration (always +).  |
|            | Deceleration   | REAL         | Deceleration (always +).  |
| VAR_OUTPUT | InVelocity     | BOOL         | Velocity reached (for the first time)                             |
|            | Active         | BOOL         | Processing of data runs after preprocessing is completed          |
|            | CommandAborted | BOOL         | Command aborted by the following command.                         |
|            | Error          | BOOL         | Indicates that an error has occurred in the FB instance.          |
|            | ErrorID        | ERROR_CODE   | Brief indication of the cause for error                           |
|            | ErrorIdent     | ERROR_STRUCT | Detailed information regarding the error                          |

# PLCopen – AXIS\_REF



```

(* Structure of PLCopen element AXIS_REF. The AXIS_REF is a structure that contains *)
(* information on the corresponding object. *)
(* It is used as a VAR_IN_OUT in all Motion Control Function Blocks. *)
TYPE AXIS_REF :
STRUCT
  CntrlNo: CONTROLS := LOCAL_CNTRL; (* Control number init: local control *)
  AxisNo: OBJECTS := NO_OBJECT; (* Axis reference number, init: no object *)
END_STRUCT
END_TYPE
    
```

**AXIS\_REF**

- ... is used as a “key” to designate a specific axis
- ... unique reference to an axis of the system
- VAR\_IN\_OUT of all PLCopen Function blocks
- Definition is manufacturer-specific

# Function Blocks according to PLCopen

| Parameter access          | Single axis commands         | Multi axes commands     | Robot Control                |
|---------------------------|------------------------------|-------------------------|------------------------------|
| MC_ReadActualPosition     | MC_Power                     | MC_CamIn                | MC_AddAxisToGroup            |
| MC_ReadStatus             | MC_MoveAbsolute              | MC_CamOut               | MC_RemAxisFromGroup          |
| MC_ReadAxisError          | MC_MoveRelative              | MC_GearIn               | MC_GroupReset                |
| MB_Command                | MC_MoveAdditive              | MC_GearOut              | MB_GroupReadListParameter    |
| MB_ReadLintParameter      | MC_MoveVelocity              | MB_GearInPos            | MB_GroupReadParameter        |
| MB_ReadListParameter      | MB_Home                      | MB_Phasing              | MB_GroupRealRealParameter    |
| MB_ReadLrealParameter     | MC_Stop                      | MB_PhasingSlave         | MB_GroupReadSercosAttribute  |
| MB_ReadLrealListParameter | MC_Reset                     | MB_PhasingSlave         | MB_GroupReadSercosDataStatus |
| MB_ReadParameter          | MC_TorqueControl             |                         | MB_GroupReadStringParameter  |
| MB_ReadRealParameter      | MB_ChangeCamData             | MB_MotionProfile        | MB_GroupWriteListParameter   |
| MB_ReadSercosAttribute    | ML_OpenCyclicPositionChannel | ML_FlexProfile          | MB_GroupWriteParameter       |
| MB_ReadSercosDataStatus   | ML_OpenCyclicAnalogChannel   | MB_ChangeCamData        | MB_GroupWriteRealParameter   |
| MB_ReadStringParameter    | ML_OpenCyclicTorqueChannel   | MB_ChangeFlexEventSet   | MB_GroupWriteStringParam.    |
| MB_WriteLintParameter     | ML_OpenCyclicVelocityChannel | MB_ChangeFlexProfileSet | MB_IRDProgSelect             |
| MB_WriteListParameter     | ML_WriteCyclicPosition       | MB_ChangeProfileSet     | MB_IRDProgStart              |
| MB_WriteLrealParameter    | ML_WriteCyclicAnalogI        | MB_ChangeProfileStep    | MB_IRDProgStop               |
| MB_WriteParameter         | ML_WriteCyclicTorquel        |                         |                              |
| MB_WriteRealParameter     | ML_WriteCyclicVelocity       |                         |                              |
| MB_WriteStringParameter   |                              |                         |                              |

MC\_xxx specified according to PLCopen

MB\_xxx Bosch Rexroth standard

ML\_xxx MLC specific



# Standard and System-specific FBs, Portability


|                   | Scope                  | Präfix      | Beispiel               |
|-------------------|------------------------|-------------|------------------------|
| Standard          | PLCopen                | <b>MC_</b>  | MC_MoveVelocity        |
|                   | Rexroth Standard       | <b>MB_</b>  | MB_ReadParameter       |
| System-spezifisch | MLC                    | <b>ML_</b>  | ML_FlexProfile         |
|                   | MLC + H                | <b>MH_</b>  | MH_HydrControl         |
|                   | MLD                    | <b>MX_</b>  | MX_SetDeviceMode       |
|                   | Visual Motion          | <b>MV_</b>  | MV_Hysteresis          |
|                   | Synax                  | <b>MS_</b>  | MS_ReadSingleParameter |
|                   | MTX                    | <b>MT_</b>  | MT_CplData             |
|                   | IndraLogic             | <b>IL_</b>  | IL_ParameterChannel    |
|                   | Synax und VisualMotion | <b>MSV_</b> | MSV_ReadMaxValue       |





## AxisInterface – Why?

- AxisInterface bundles all functions which are available with PLCopen to a concise and simple data interface
- Bidirectional communication
  - arAxisCtrl\_gb – Command interface
  - arAxisStatus\_gb – State information
- Less PLCopen knowledge required
- Faster program development and clean code thanks to automatic code generation
- Good usability due to “Intellisense”
- Ready-to-use IndraLogic visualization for easy commissioning
- Complete documentation available

# AxisInterface – Data structure arAxisCtrl\_gb




# AxisInterface – Cyclic and non-cyclic scanning




|                     |
|---------------------|
| Cyclic scanning     |
| Non-cyclic scanning |

# AxisInterface – Data structure arAxisStatus\_gb



## AxisInterface – Application example



- Phase synchronization of the Fin seal axis
  - Master: virtualAxis1
  - Ratio 3:2
  - absolute synchronization
  - dynamic synchronization only in positive direction

### Sample program:


```
arAxisCtrl_gb[SealAxis.AxisNo].SyncMode.Master := virtualAxis1;
arAxisCtrl_gb[SealAxis.AxisNo].SyncMode.InputRev := 3;
arAxisCtrl_gb[SealAxis.AxisNo].SyncMode.OutputRev := 2;
arAxisCtrl_gb[SealAxis.AxisNo].SyncMode.StartMode := ABSOLUTE;
arAxisCtrl_gb[SealAxis.AxisNo].SyncMode.SyncDirection := POS_DIRECTION;
arAxisCtrl_gb[SealAxis.AxisNo].Admin._OpMode.en := ModePhaseSync;
```

# AxisInterface – Automated Code creation

```
//-----
//----- Call all required programs --> Imc a
//-----

TE_AxisInterfaceType01Prog ();
MB_ImcInterface ();

IF TE_AxisInterfaceType01Prog.InitDone=
    RETURN;
END_IF
```



- A input form comes up in which the axis and the operating mode can be selected
  - Additionally the command values for the selected operating mode are entered
  - Based on these inputs, ST code is created, which translates the input data into program code for the AxisInterface
  - As an option acknowledgement code can be created, to check if the operation is successful
- Saving of time + less error-prone!**

# AxisInterface – Automated Code creation

Generate ST Code

**Command Axis**  
Enter the required parameters.  
The code is inserted in the current editor cursor position.

Absolute positioning

| Properties   | Value                | Default Value |
|--------------|----------------------|---------------|
| Axis*        | Axis 1               |               |
| Position     | rPosition_Axis 1     | 0.0           |
| Velocity     | rVelocity_Axis 1     | 10.0          |
| Acceleration | rAcceleration_Axis 1 | 10.0          |
| Deceleration | rDeceleration_Axis 1 | 10.0          |

Comment

Generate acknowledgement code

Finish Cancel Help

Set operating mode

Select axis

Enter command values (concrete values or variables)

Acknowledgement code as an option

With „Finish“ the code will be created

# AxisInterface – Automated Code creation

```
//-----
//----- Call all required programs --> Imc and Axis Interface Update -----
//-----
TE_AxisInterfaceType01Prog();
MB_ImcInterface();

IF TE_AxisInterfaceType01Prog.InitDone=FALSE THEN
    RETURN;
END_IF
```

Generated code

```
arAxisCtrl_gb[Axis1.AxisNo].PosMode.Position := rPosition_Axis1;
arAxisCtrl_gb[Axis1.AxisNo].PosMode.Velocity := rVelocity_Axis1;
arAxisCtrl_gb[Axis1.AxisNo].PosMode.Acceleration := rAcceleration_Axis1;
arAxisCtrl_gb[Axis1.AxisNo].PosMode.Deceleration := rDeceleration_Axis1;
arAxisCtrl_gb[Axis1.AxisNo].Admin_OpMode.en := ModePosAbs;

(* Code example to check if the commanded operation mode is acknowledged
IF ((arAxisStatus_gb[Axis1.AxisNo].Admin_OpModeAck = ModePosAbs) AND (arAxisStatus_gb[Axis1.A:
// commanded operation mode is acknowledged
;
END_IF
*)|
```

The commented code can be used to check if the command was successful



# AxisInterface – Online Help

A complete description of the AxisInterface is available in the Online Help

The following acknowledgement has to follow the operation mode:

```

arAxisCtrl_gb[ ].Admin._OpMode.en:= ModePosAbs;
arAxisCtrl_gb[ ].Admin._OpMode.b.MODE_POS_ABS:= TRUE;
    
```

The following acknowledgement has to follow the operation mode command. It returns TRUE, when the drive reached its target position:

```

arAxisStatus_gb[ ].Admin.CmdDone
    
```


The AxisInterface uses the MC\_Power and MC\_MoveAbsolute (PLCopen.library) internally to carry out the switchover.

**Attributes supported by this operation mode:**

| Element            | Name                 | Type     | Default | Cyclically scanned |
|--------------------|----------------------|----------|---------|--------------------|
| arAxisCtrl_gb[ ]   | PosMode.Position     | REAL     | 0.0     | Yes                |
|                    | PosMode.Velocity     | REAL     | 10.0    | Yes                |
|                    | PosMode.Acceleration | REAL     | 10.0    | No                 |
|                    | PosMode.Deceleration | REAL     | 10.0    | No                 |
|                    | Admin.Axis           | AXIS_REF |         | No                 |
| arAxisStatus_gb[ ] | Admin.MODE_POS_ABS   | BOOL     |         | Not applicable     |
|                    | Admin.CmdDone        | BOOL     |         | Not applicable     |

"Absolute Positioning" attributes

# AxisInterface – Function Blocks



# AxisInterface – Cyclic call of system code

```

1 PROGRAM PlcProg
2 VAR
3
4 END_VAR

1 //-----
2 //----- Call all required programs --> Imc and Axis Interface Update -----
3 //-----
4 TE_AxisInterfaceType01Prog();
5 MB_ImcInterface();
6
7 IF TE_AxisInterfaceType01Prog.InitDone=FALSE THEN
8     RETURN;
9 END_IF
10
    
```

Inside TE\_AxisInterfaceType01Prog the function blocks of the AxisInterface are called!

No commands can be issued during the initialization of the AxisInterface! The RETURN statement ensures that the following statements are not executed!

Don't modify these statements, otherwise the AxisInterface will not work properly!



# AxisInterface – IndraLogic Visualization


Clear Error
P2
Machine Overview
Remote On

Error


|                  |                                       |
|------------------|---------------------------------------|
| Diagnosis Number | E00B0179                              |
| Diagnosis Text   | E00B0179, sercos III: Redundanzfehler |

Control Overview

| Axis Details / Diagnosis   | Status   | Position Velocity  | SetupMode  |
|--|--|--|--|
| << Axis: <b>AXIS_2</b> <span style="color: green;">Active</span> ErrorID: NONE_ERROR<br>vAxis2 ErrorTable: NO_TABLE_USED<br>Warning Error Axis Type: <b>VIRTUAL</b> ErrorAdd1: 16#0 ErrorAdd2: 16#0<br>Diagnosis: <b>not in operating mode</b> | Status: <b>ModeAB</b><br>BB AB AH AF In Ref<br>Flex Profile: Set0 OK Set1 OK Set2 OK Set3 OK Flex sync Flex active | Position: 37.82<br>Velocity: 0.00<br> | Setup Mode: Enable<br>Vel: 10 Jog+<br>Accel: 10 Jog-<br>Home |
| << Axis: <b>AXIS_1</b> <span style="color: green;">Active</span> ErrorID: NONE_ERROR<br>Axis1 ErrorTable: NO_TABLE_USED<br>Warning Error Axis Type: <b>REAL</b> ErrorAdd1: 16#0 ErrorAdd2: 16#0<br>Diagnosis: <b>not in operating mode</b>     | Status: <b>ModeAB</b><br>BB AB AH AF In Ref<br>Flex Profile: Set0 OK Set1 OK Set2 OK Set3 OK Flex sync Flex active | Position: 0.00<br>Velocity: 0.00<br>  | Setup Mode: Enable<br>Vel: 10 Jog+<br>Accel: 10 Jog-<br>Home |

- 
  - IndraLogic Visualization is part of the AxisInterface
  - After adjustment of the visualization to the correct axis configuration the axis can be commanded immediately without any coding!

# ImcInterface – ImcCtrl and ImcStatus



# AxisInterface – How to get the Axis Interface?

The image shows the 'Project Explorer' on the left, where the 'GAT' folder is selected under the 'MLC\_XM22' project. A context menu is open over the 'GAT' folder, with 'GAT' highlighted. A blue arrow points from this menu to the 'Import Template' dialog on the right.


The 'Import Template' dialog is titled 'PLC Application' and contains the following sections:

- Active application:** MLC\_XM22\Logic\Application
- Sample projects:**
  - AxisInterface** (Sample project explaining the use of the AxisInterface)
  - GAT compact (Sample project for ordinary non-modular machine concepts)
- Templates:**
  - GAT (central state machine)** (Template for modular machines with central state machine and state coupling of the modules). This option is selected. Below it is a diagram of a 'Central State Machine' with a 'State' block at the top, connected to 'Module 1' and 'Module 2', which are both connected to an 'Axis / Control Interface' block at the bottom.
  - GAT (decentral state machine)** (Template for modular machines without state coupling of the modules). Below it is a diagram of 'Operation Mode Coordination' with two 'Unit' blocks, each containing a state machine diagram, connected to an 'Axis / Control Interface' block.
  - User-defined GAT** (Imports the selected GAT folder ivx file. The GAT libraries and tasks are added).
- Plugins:**
  - AxisInterface Extended
  - Kinematics Interface
  - Sercos Diagnosis
  - HydraulicBasic
  - MicTrending
  - Profibus Diagnosis

Buttons at the bottom of the dialog include 'Finish', 'Cancel', and 'Help'.

# Programming Guidelines for IndraLogic

- A cross-system working group has elaborated IndraLogic programming guidelines
- Aim: unify all functions, function blocks etc. across systems
- Definitions and recommendations for different subjects:
  - Standardized headers for function blocks
  - History
  - Type identifiers
  - Variable identifiers
  - Constant identifiers
  - Interfaces of function blocks
  - Error handling
  - Names of libraries
  - Versioning of libraries



# IL Guidelines – Standardized header

```

(#####*)
(#####*)

(* General Header *)
(*-----*)
(* Shortdescription      : This function block provide the communication between device xyz *)
(*                       : via Profibus and the programmable logic controller *)
(* Version               : 1.3 *)
(* Name                  : Max Mustermann *)
(* Date                  : 2004-02-02 *)
(* Company                : Bosch Rexroth AG *)
(* Target                : SYNAX200-MotionLogic; VisualMotion *)
(* Functional description : A communication with device xyz is only possible over a special *)
(*                       : multiplex process. The function block decodes and encodes the *)
(*                       : telegram and makes sure that ... *)
(* Handling specials     : Attend the following points: *)
(*                       : - It's essential that the device xyz is connected with the *)
(*                       :   control unit. *)
(*                       : - Connect the device to the Profibus and provide that the bus is *)
(*                       :   running without any error. *)
(*-----*)

(* Additional Header *)
(*-----*)
(* Customer               : Koenig & Bauer AG *)
(* Machine                : FA0815STX *)
(*-----*)

(#####*)
(#####*)
PROGRAM Z2MainProgram
VAR

```



# IL Guidelines – Prefix for type & variable identifiers

| Data type      | Prefix | Instance example      | Type example  |
|----------------|--------|-----------------------|---------------|
| Function block | fb     | fbJogAxisX1           | MT_Jogging    |
| Structure      | st     | stDeviceCommunication | MX_COM_DATA   |
| Array          | ar     | arStateControlUnit    | MV_STATE_INFO |
| Enumerator     | en     | enDeviceDiagnosis     | ML_DIAG_DATA  |

| Data type | Prefix | Example | Memory allocation | Data type designation   | Data type description                         |
|-----------|--------|---------|-------------------|-------------------------|---|
| BOOL      | b      | bVar    | 1 Bit             | Boole                   | Bit oriented boolean format                   |
| BYTE      | by     | byVar   | 8 Bit             | Byte                    | Bit oriented Byte format                      |
| WORD      | w      | wVar    | 16 Bit            | Word                    | Bit oriented format with simple word length   |
| DWORD     | dw     | dwVar   | 32 Bit            | Double Word             | Bit oriented format with double word length   |
| LWORD     | lw     | lwVar   | 64 Bit            | Long Word               | Bit oriented format with fourfold word length |
| SINT      | si     | siVar   | 8 Bit             | Short Integer           | integer signed format with shortened length   |
| INT       | i      | iVar    | 16 Bit            | Integer                 | integer signed format with simple length      |
| DINT      | di     | diVar   | 32 Bit            | Double Integer          | integer signed format with double length      |
| LINT      | li     | liVar   | 64 Bit            | Long Integer            | integer signed format with fourfold length    |
| USINT     | usi    | usiVar  | 8 Bit             | UnsignedShort Integer   | integer unsigned format with shortened length |
| UINT      | ui     | uiVar   | 16 Bit            | Unsigned Integer        | integer unsigned format with simple length    |
| UDINT     | udi    | udiVar  | 32 Bit            | Unsigned Double Integer | integer unsigned format with double length    |
| ULINT     | uli    | uliVar  | 64 Bit            | Unsigned Long Integer   | integer unsigned format with fourfold length  |
| REAL      | r      | rVar    | 32 Bit            | Real                    | real number with simple length                |

# IL Guidelines – Prefix for type & variable identifiers

| LREAL            | lr   | lrVar   | 64 Bit               | Long Real              | real number with double length                         |
|------------------|------|---------|----------------------|------------------------|--|
| STRING           | str  | strVar  | 8 Bit per character  | String                 | string of 1-255 characters (ANSI code possible)        |
| WSTRING          | wstr | wstrVar | 16 Bit per character | Wide String            | string of 1-65535 characters (UNI code possible)       |
| TIME             | t    | tVar    | 32 Bit               | Time                   | Time format  |
| DATE             | d    | dVar    | 32 Bit               | Date                   | Date format  |
| TIME_OF_DAY      | tod  | todVar  | 32 Bit               | Time Of Day            | Time of day format                                     |
| DATE_AND_TIME    | dat  | datVar  | 32 Bit               | Date And Time          | Date and time format                                   |
| POINTER TO ???   | p??? | p???    | 32 Bit               | Pointer To ???         | Pointer / address of a variable with special data type |
| POINTER TO DWORD | pdw  | pdwVar  | 32 Bit               | Pointer To Double Word | Example: Pointer to a double word variable             |

## Libraries

- IndraWorks has a two-stage library management:  
Libraries are first installed into the repository before adding them to a project
- The **Library Repository** holds all libraries which have been installed on the local system, in order that they can be bound to an IndraLogic project. In the Library Repository is a link to the folder where the library is located.
- In the **Library Manager** the libraries which are available in the repository can be added to a project. Consequently the functions, function blocks or other elements of the library (e.g. data types) can be used in the project.

## Libraries for IndraMotion MLC

|                            |  |
|----------------------------|--|
| <b>ML_Base_...</b>         | Data types and variables which are particular for the systems IndraMotion MLC and IndraLogic XLC.<br>Functions, function blocks and methods to access the concrete control hardware. |
| <b>ML_PLCopen</b>          | PLCopen function blocks for the programming of real axes (sercos-based), virtual axes etc.<br>Functions for read and write access to control and axis parameters.                    |
| <b>ML_TechInterface</b>    | IMC Interface and Axis Interface for programming of real and virtual axes etc.   |
| <b>RMB_PLCopenFieldBus</b> | PLCopen function blocks for the programming of field bus-based axes  |
| <b>ML_Robot</b>            | Data types, functions and function blocks for robot applications   |

## Libraries for IndraMotion MLC


|                            |  |
|----------------------------|--|
| <b>RIL_CheckRtv</b>        | Implicit check of division by 0, access to array elements, pointer access, etc.  |
| <b>RIL_CommonTypes</b>     | Data types for PLCopen function blocks   |
| <b>RIL_Uilities</b>        | Common IL functions and function blocks  |
| <b>RIL_ProfibusDP_Util</b> | Archiving and restoring of DP/V1 parameters of ProfibusDP/V1 devices; functions for drives connected via PROFIBUS (PROFIdrive) |
| <b>RIL_ModbusTCP</b>       | Diagnosis and Communication services for Modbus/TCP  |
| <b>RIL_SocketComm</b>      | Basic functions for TCP/IP and UDP communication   |
| <b>RIL_LoopControl</b>     | Basic elements and controllers   |
| <b>RIL_NetXLoad</b>        | Only for internal use  |
| <b>RIL_HMI_Uilities</b>    | Functions to access M-Keys on a HMI  |
| <b>RIH_CMLx</b>            | Hardware information of CML25/L45/L65 (OHC, temperature, electronic typeplates, display of messages)                           |

# Libraries for IndraMotion MLC

|                               |  |
|-------------------------------|--|
| <b>ML_TechBase</b>            |  |
| <b>ML_TechMotion</b>          |  |
| <b>ML_TechReg</b>             |  |
| <b>ML_TechCrank</b>           |  |
| <b>ML_TechTensionAdvanced</b> |  |
| <b>RMB_TechWinder</b>         |  |
| <b>RMB_CrosscutCrossseal</b>  |  |
| <b>RMB_TechCam</b>            |  |
| <b>RIL_ParameterChannel</b>   |  |




# Global Data as interface to the motion kernel (axis)



SIDEX

# Global Data as interface to the motion kernel (MLC)





## Global Data related to axes

- AxisData is an array with elements of type ML\_AXISDATA\_SM
  - This axis-specific structure holds „per axis“ information like:
    - **Axis state information, e.g.**  
AxisData[1].Axis\_InVelocity
    - **Actual values for Position, Velocity and Force/Torque, e.g.**  
AxisData[1].rActualPosition\_i  
AxisData[1].rActualVelocity\_i
    - **Container for customized command values and actual values**  
AxisData[1].dwUserCmdDataA\_q  
AxisData[1].dwUserActualDataC\_i
- DV\_Axis is an array with elements of type ML\_DirectVarAxis
  - **Access to A-Parameters**  
DV\_Axis[1].A\_0\_0100 // actual position  
DV\_Axis[1].A\_0\_0102 // actual velocity
- arAxisStatus\_gb is an array with elements of type TE\_STATUS\_DATA
  - **Access to axis state information, e.g.**  
arAxisStatus\_gb[1].Admin.OpModeAck // operating mode  
arAxisStatus\_gb[1].Admin.CmdDone // cmd acknowledgement

## Global Data related to control

- ControlData is an array with elements of type ML\_CONTROLDATA\_SM
  - It holds information on Sercos etc, e.g.
    - **Redundancy warning active**  
ControlData[LOCAL\_CNTRL].arSercos[ML\_LOCAL\_SERCOS\_IFC].ERROR\_RED
    - **Flag to recover Sercos ring**  
ControlData[LOCAL\_CNTRL].arSercos[ML\_LOCAL\_SERCOS\_IFC].RBUILD\_RING
    - **Sercos cross communication**  
ControlData[LOCAL\_CNTRL].arLinkSyncBits\_i[...]. ...
- DV\_Control is an array with elements of type ML\_DirectVarControl
  - **Access to C-Parameters**


```
DV_Control[LOCAL_CNTRL].C_0_0023           // system status
DV_Control[LOCAL_CNTRL].C_0_0070         // control temperature
```
- ImcStatus is an array with elements of type MB\_IMC\_STATUS\_TYPE01
  - **Access to control state information**

```
ImcStatus[LOCAL_CNTRL].Admin._OpModeAck   // Sercos phase
ImcStatus[LOCAL_CNTRL].Diag.Error         // error pending
```

## Agenda

- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information

# System Diagnosis



- Display of **device status**
- Function for **clearing errors**
- **Diagnosis / error memory** for the entire system (max. 1000 entries)
- List of invalid parameters
- Overview on task configuration
- Monitoring of the task execution

# Diagnosis / Error memory

- Message categories

| Categories | Note   |
|------------|--|
| Message    | Status information of message type   |
| Error      | Error reaches, the error reaction is triggered, the error is active                          |
| Error      | Error passive, the error cause still exists, but the error was reset                         |
| Error      | Error leaves, the error cause does not exist any longer <b>and</b> the error was reset       |
| Warning    | Warning reached, the warning reaction is triggered, the warning is active                    |
| Warning    | Warning passive, the warning cause still exists, the warning was reset                       |
| Warning    | Warning leaves, the warning cause does not exist any longer <b>and</b> the warning was reset |

- Display of messages

Clear Error max. 10 most recent entries

| Category | Time                 | Source       | Status Code | Text                                    |
|----------|----------------------|--------------|-------------|---|
| Message  | 4/11/2007 5:23:01 PM | IndraControl | A0200003    | P2 STOP, reached phase 2, PLC in stop   |
| Error    | 4/11/2007 5:23:00 PM | IndraControl | F0160021    | RTOS error (Real Time Operating System) |
| Message  | 4/11/2007 5:22:59 PM | IndraControl | A00C0001    | BOOT END, boot up of control finished   |
| Message  | 4/11/2007 5:22:59 PM | IndraControl | A0200001    | P0 STOP, reached phase 0, PLC in stop   |
| Message  | 4/11/2007 4:09:39 PM | IndraControl | A0200003    | P2 STOP, reached phase 2, PLC in stop   |
| Message  | 4/11/2007 4:09:39 PM | IndraControl | A0200001    | P0 STOP, reached phase 0, PLC in stop   |
| Message  | 4/11/2007 4:09:38 PM | IndraControl | A0200005    | BB STOP, Motion ready, PLC in stop      |
| Error    | 4/11/2007 4:09:38 PM | IndraControl | F0160021    | RTOS error (Real Time Operating System) |
| Message  | 4/11/2007 4:09:37 PM | IndraControl | A0200004    | P3 STOP, reached phase 3, PLC in stop   |
| Message  | 4/11/2007 4:09:37 PM | IndraControl | A0200003    | P2 STOP, reached phase 2, PLC in stop   |

# Axis Diagnosis

- Display of axis status and drive status
- Function Clear errors

The screenshot shows the software interface for Axis Diagnosis. On the left, a context menu is open with 'Diagnosis' selected, which has opened a sub-menu with 'State' selected. The 'State' sub-menu includes options like 'Clear Error', 'Error/Diagnostic Memory', and 'Average Value Filter'. The main window displays the 'Axis Status - Axis1' window. At the top, it shows 'Axis number 1', 'Axis name Axis1', 'Drive address 1', and 'Axis Type Real axis'. The status is 'Axis is in Synchronized Motion'. Below this, a table shows current values: Actual position (359.9979 Deg), Actual velocity (14.877 Rpm), Actual acceleration (21.283 rad/s<sup>2</sup>), and Actual torque/force (-2.1 %). The motion is 'Synchronized Motion with master axis'. The drive status is 'A0132 Cam shaft, lagless, encoder 1, virt. master axis'. The power section shows 'Ready for power on "bb"', 'Ready for operation, torque-free "Ab"', and 'In operation, with torque "AH/AF"'. The errors/warnings section shows 'Warning exists' and 'Error exists' are unchecked. The messages section shows 'Standstill', 'Target position reached', 'In Velocity', 'In Reference', and 'Synchronized' are checked.

# Display of pending errors, warnings, and infos



Colored icon indicates pending error / warning

By pushing the button the internal **diagnosis / error memory** is displayed. It holds diagnostic information of the overall system (max. 1000 entries)

Error-/Diagnostics Memory - MLC\_x

MLC\_x

Clear Error

10 Read in entries

| Category | Time                  | Source        | Status C... | Text                                   |
|----------|-----------------------|---------------|-------------|--|
| Message  | 2/18/2010 10:10:56 PM | IndraControl  | A0200003    | P2 STOP, reached phase 2, PLC in st... |
| Message  | 2/18/2010 10:10:55 PM | IndraControl  | A0200001    | P0 STOP, reached phase 0, PLC in st... |
| Message  | 2/18/2010 10:10:55 PM | IndraControl  | A00C0001    | BOOT END, boot up of control finished  |
| Message  | 2/18/2010 10:09:11 PM | IndraControl  | A00C0002    | ErrClear, Error cleared                |
| Message  | 2/18/2010 10:08:15 PM | Axis 4 (V...) | A0110002    | Axis has been created                  |
| Message  | 2/18/2010 10:08:15 PM | Axis 3 (V...) | A0110002    | Axis has been created                  |
| Message  | 2/18/2010 10:08:15 PM | Axis 2 (F...) | A0110002    | Axis has been created                  |
| Message  | 2/18/2010 10:08:14 PM | Axis 1 (F...) | A0110002    | Axis has been created                  |
| Message  | 2/18/2010 10:08:10 PM | IndraCo...    | A0200003    | P2 STOP, reached phase 2, PLC in st... |
| Message  | 2/18/2010 10:08:09 PM | IndraCo...    | A00C0001    | ErrClear, Error cleared                |

After a double click on an entry the Online Help opens and you get more information on the occurred error or warning!

## Diagnosis concept

- MLC has a consistent diagnostic system
- Every MLC diagnosis info has a 8-digit diagnosis code as a unique identifier
- The 8-digit diagnosis code is displayed as well as a plain text message in German or English language (for MLC)
- The IndraDrive has some more languages available ...
- Diagnosis infos are displayed
  - in IndraWorks (Device status, Axis-/Drive status)
  - in the MLC-internal diagnosis memory (in chronological order)
  - on the display of IndraControl L25/45/65/75
  - Error output of PLCopen function blocks, technology function blocks etc.




# Diagnosis codes

8-digit diagnosis code

**F50B0002**

plain text message

SERCOS ring interrupted



## Diagnosis codes – Identifier & Severity

### Diagnostic identifier

- Currently, 4 different categories are supported:
  - F - Error
  - C - Command error
  - E - Warning
  - A - Message
- Priority is defined as follows: F > C > E > A

### Severity of the diagnostic

- Currently ten degrees of severity are supported for the MLC:
- F9 > ... > F1 > F0 ; C9 > ... > C1 > C0 ; E0 ; A0.

## Diagnosis codes – Severity

| Severity | Description /Designation                                 | Error reaction   |
|----------|--|--|
| 0        | Non-fatal error  | Logbook entry is generated, message is shown on the display, no error reaction.  |
| 1        | Axis group error   | Logbook entry is generated, message is shown on the display, If an axis belonging to a group activates an error of severity F2, Disengage the axis, then this axis is currently lost to the group and the group reacts with an F1 error, disengaging <b>all</b> axes in the group. |
| 2        | Axis error   | A logbook entry is generated, a message is shown on the display, Axis (or drive) is disengaged as best as possible, all other axes are unaffected by this.   |
| 3/4      | Reserved   | -  |
| 5        | Controller error   | A logbook entry is generated, a message is shown on the display, <b>All</b> axes are disengaged as best as possible.   |
| 6        | Reserved   | -  |
| 7        | Reserved   | -  |
| 8        | Fatal controller error                                   | A logbook entry is generated, a message is shown on the display, <b>All</b> axes are disengaged as best as possible.   |
| 9        | Fatal system error<br>Exception, undefined system status | A logbook entry is generated, a message is shown on the display, Firmware no longer working, request for FatalSystemErrorHandler (), no error reaction to the drive, torque disable.   |

# Diagnosis codes – Group


## Diagnosis group

- ... indicates which component has caused an error etc.

| Group   | Cause / Error Table   |
|---------|---|
| 00      | IndraDrive drive/ INDRV_TABLE (see <a href="#">IndraDrive Drive Errors</a> , <a href="#">IndraDrive Drive Warning</a> ) |
| 01...A9 | MLC firmware, e.g. a virtual axis error <a href="#">Virtual Axis, Error Message</a>                                     |
| 2D      | SERCOS error/ SERCOS_TABLE <a href="#">SERCOS error message</a>   |
| 2E      | Generic axis / generic drive <a href="#">Generic Axis/SercosDrive, Error Message</a>                                    |
| AE      | User program (to be provided by the user)   |

- Drive errors are translated as follows:
  - IndraDrive error **F4034 Emergency-Stop**
  - Expansion to 8 digits → **F2004034**
  - Severity 2, no other axis is affected
  - Diagnosis group 00 → IndraDrive
  - S-0-0390 F4034**
  - A-0-0020 “Drive Error”**
  - A-0-0023 F2004034**
  - Lx5 display: **“Axis1 F2004034 Drive error“**

# Error information in the motion program



(\* Structure to implement the diagnostics of the function block \*)

```

TYPE ERROR_STRUCT :
STRUCT
    Table          : ERROR_TABLE; (* Additional diagnosis table *)
    Additional1    : DWORD; (* Contains the error number diagnostics *)
                    (* corresponding to the table. *)
    Additional2    : DWORD; (* eventually supplements to Additional1 *)
END_STRUCT
END_TYPE
    
```

## Error information in the motion program

(\* Enumeration of valid tables in additional information \*)

TYPE ERROR\_TABLE:

```
(
  NO_TABLE_USED      := 16#0000, (* reserved *)
  SERCOS_TABLE       := 16#0010, (* sercos : Additionall = sercos code *)
  MLD_TABLE          := 16#0020, (* Drive-based Motion - Logic *)
  MLC_TABLE          := 16#0030, (* Controller-based Motion Logic *)
  MTX_TABLE          := 16#0040, (* CNC *)
  MLP_TABLE          := 16#0050, (* PC-based Motion Logic *)
  PLC_TABLE          := 16#0060, (* PLC *)
  INDRV_TABLE        := 16#0070, (* IndraDrive *)
  ...                (* DIAX, EcoDrive, Profibus, DeviceNet, *)
                    (* Ethernet, EtherNet/IP, Interbus, *)
                    (* function related, CAN *)
  INLINEIO_TABLE     := 16#0190, (* Inline IO bus *)
  USER1_TABLE        := 16#1000, (* free User Table *)
                    (* ... *)
  USER10_TABLE       := 16#1009 (* free User Table *)
);
END_TYPE
```

# Error information in the motion program

The screenshot shows the IndraWorks 10VRS interface. On the left, the 'Inhalt' (Table of Contents) pane is open, with 'MLC/MLP Diagnostic System' expanded. The 'Diagnostic Numbers in the PLC Program' option is highlighted with a red circle. The main window displays the 'MLC/MLP Diagnostic System 10VRS' configuration page, which includes a text description of the diagnostic system and a diagram of the 'MC\_MoveAbsolute' function block. The diagram shows inputs like 'Execute', 'Position', 'Velocity', 'Acceleration', 'Deceleration', and 'Axis' (of type 'AXIS\_REF'). It also shows outputs like 'Done', 'Active', 'CommandAborted', 'Error', 'ErrorID', and 'ErrorStruct' (of type 'ERROR\_STRUCT'). The 'ErrorStruct' output is highlighted in yellow. Below the diagram, there is a code snippet for the 'ERROR\_STRUCT' type definition.

**MLC/MLP Diagnostic System 10VRS**  
Diagnostic Numbers in the PLC Program

PLCopen function blocks are provided with an error management that displays errors with a 0/1 transition on the error bit, briefly gives the errorID at the output with an enum text and provides a detailed description via the ErrorIdout output.

**MC\_MoveAbsolute**

|          |              |                |              |
|----------|--------------|----------------|--------------|
| BOOL     | Execute      | Done           | BOOL         |
| REAL     | Position     | Active         | BOOL         |
| REAL     | Velocity     | CommandAborted | BOOL         |
| REAL     | Acceleration | Error          | BOOL         |
| REAL     | Deceleration | ErrorID        | ERROR_CODE   |
| AXIS_REF | Axis         | ErrorStruct    | ERROR_STRUCT |
|          |              | Axis           | AXIS_REF     |

Error management as illustrated by the FB MC\_MoveAbsolute

Program:

```
(* Structures to implement the diagnostics of the function block
TYPE ERROR_STRUCT :
STRUCT
  Table      : ERROR_TABLE; (* Additional diagnosis table
  Additional1 : DWORD;      (* Contains the error number (diagnostics)*
  (* corresponding to the table.
  Additional2 : DWORD;      (* can contain supplements to "Additional1".
END_STRUCT
```

## Agenda

- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information




## Sercos – What does it mean?

**s**erial  
**r**ealtime  
**c**ommunication  
**s**ystem


# Sercos – Sercos 2 and Sercos III

## Sercos 2

## Sercos III



# Sercos – Features




Cyclic real-time traffic

Cross communication (CC)


Standard Ethernet traffic

# Sercos – Features





- Redundancy (as of MLC13)
- Hot Plug (not supported by MLC)

## Sercos – Communication phases




# Sercos – IndraDrive Display



## Sercos – Redundancy

- Redundancy is supported for ring topology
- After a break at an arbitrary position the ring is decomposed into a double line
- All Sercos devices remain accessible, there is no interruption of communication
- After reestablishing the connection at the defective position
- ... and executing the command “Restore redundancy” the double line is converted back to a ring



# Sercos – Redundancy

**sercos Eigenschaften - MLC\_L65**

MLC\_L65

Busdiagnose | E/A-Diagnose | Einstellungen

Allgemein

Erlaubte Telegrammausfälle: 2

Redundanz

Redundanzerkennung: **Redundanzerkennung ein**

- Redundanzerkennung ein
- Keine Redundanzerkennung
- Redundanzerkennung ein
- Redundanzerkennung mit Ringwiederherstellung

No detection of redundancy loss (for line topology)

Detection of redundancy loss (automatic recovery)

Detection of redundancy loss (“manual” recovery)

If line topology is used detection of redundancy loss has to be disabled (C-0-0-0506), otherwise the warning “E00B0179 Sercos III: Redundancy error” is displayed permanently!



# Agenda


- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information

# Archiving IndraWorks projects


For which purpose you need an archived IndraWorks project?

- **Service**  
For diagnosis purposes, drive replacement, and other service tasks a valid IndraWorks project is required
- **Support**  
A qualified support can be done based on the complete IndraWorks project. For this purpose the exchange of a complete IndraWorks archive is very useful
- **Serial machines**  
The IndraWorks project is required to duplicate machines


# Archiving IndraWorks projects



# Archiving IndraWorks projects




- Invoke the Archiving function via menu or toolbar
- ... IndraWorks is in online mode
- ☞ Switch Sercos to CP2 and stop the PLC!




- Enter an archive name
- Optionally you can protect the archive by a password

# Archiving IndraWorks projects




- Specify the target directory and/or
- the device name or IP address of the MLC
- (storage on a FTP server is also supported)




- Add IndraLogic libraries to archive

# Archiving IndraWorks projects




- **Tab “General”:**
- Select control data (includes drive data)
- Select User and OEM partition
- Select new backup or an existing backup, which is still up-to-date



- **Tab “Control data”:**
- Mark all parameters
- Select option “Archive parameters required for restoring”

# Archiving IndraWorks projects




- During the archive operation the selected data is transferred to the engineering PC
- ... and stored in a subfolder of the current IndraWorks project

| Name            | Größe     | Typ         | Geändert am      |
|-----------------|-----------|-------------|------------------|
| CF_OEM.zip      | 105 KB    | zip Archive | 06.05.2010 19:06 |
| CF_System.zip   | 6.506 KB  | zip Archive | 06.05.2010 19:07 |
| CF_User.zip     | 14.010 KB | zip Archive | 06.05.2010 19:06 |
| DeviceData.meta | 1 KB      | META-Datei  | 06.05.2010 19:07 |
| Params.par      | 344 KB    | PAR-Datei   | 06.05.2010 19:06 |

- Subfolder “ArchivedData” in current IndraWorks project

## Archiving IndraWorks projects

- Finally the complete IndraWorks project is zipped and stored as an archive in the specified target directory
- ... and/or on the CF card of the MLC (partition OEM)
- The successful result is displayed:







## Restoring IndraWorks projects

- Restoring an MLC project archive may occur in different scenarios:
  - Service – diagnosis  
A service engineer restores an IndraWorks project to his own engineering notebook to perform service tasks on a running machine. After restoring the project direct switching to online mode is possible without downloading anything to MLC
  - Service – exchange of control or drive components  
In case of drive replacement etc. parameters have to be downloaded to the new drive.
  - Duplicating machines – 1<sup>st</sup> time installation  
The IndraWorks project is used to duplicate an existing machine. In this case all device data (control & drive parameters, CF partitions) have to be restored
  - Support of a customer  
During the commissioning phase of a machine the complete IndraWorks archive can be forwarded to Bosch Rexroth for further processing. After fixing a problem the revised project is returned to the customer

# Restoring IndraWorks projects




- To restore push the button “Restore project”
- You can restore from the HDD
- ... or from IndraMotion MLC




- If you restore from the file system specify the path and name of the archive

# Restoring IndraWorks projects




- If you want to restore from the CF card
- ... enter an IP address or host name
- ... and push “Connect” button




- A list of the archived project(s) on the CF is displayed
- Select the appropriate entry and push the “Next” button

# Restoring IndraWorks projects




- Enter the target directory on your HDD to which you want to restore to




- A summary of the operations to be performed is displayed
- Push the “Finish” button to acknowledge the restore procedure

# Restoring IndraWorks projects




- As a result is transferred from the MLC and unzipped
- ... or directly unzipped from the HDD

# Restoring IndraWorks projects




- On completion the result of the restore operation is displayed
- ... and you can immediately open the restored project
- ... mark the checkbox “Open project when closing the wizard” and and press the “Close” button

- A reminder is displayed because eventually device data must be restored




# Restoring IndraWorks projects




- To restore the Device Data switch to Online mode
- In version 14 the motion configuration is not downloaded automatically when going online
- Before restoring the device data, the motion configuration has to be downloaded
- Subsequently select the submenu entry “Device Data/Restore”

# Restoring IndraWorks projects




- Select what you want to restore
- In most cases you will restore the complete control data (control & drive parameters)
- ... as well as User & OEM partition



- On the tab "Control data" select the items you want to restore
- In this case restore the complete parameter set




# Restoring IndraWorks projects




- A summary of the procedure to be performed is displayed
- Acknowledge this operation by pushing the “Finish” button

- As a result the selected partitions
- ... and the selected control and drive parameters are restored




## Restoring IndraWorks projects

- After all data has been downloaded to the MLC
- ... the successful result is displayed:




# Export of control or drive parameters




- **Parameter export**
- If you want to save the actual parameter values of your control and / or drives
- ... select the submenu entry “Parameter/Export”
- This is necessary for instance before downloading a new firmware

# Export of control or drive parameters




- Select “Archive parameters required for restoring”
- Export of all parameters or
- ... only of selected parameters is supported
- Push “All” to export the complete parameter set

- The parameter file is stored **within** the IndraWorks project folder
- If needed a subfolder for the parameter file can be created
- Enter a filename for the parameter file




## Export of control or drive parameters

- The parameters are uploaded from MLC and stored in a parameter file
- During this procedure the actual progress is displayed




- On completion this information is displayed




- As a result the parameters are saved in the parameter file which can be imported later on

# Import of control or drive parameters




- **Parameter import**
- If you have a parameter file you can download the parameters to the MLC and in this way restore a prior state
- **Before importing parameters switch the control to parameter mode**
  - ... then select the submenu entry “Parameter/Import”
- This procedure is necessary for instance after a firmware upgrade

# Import of control or drive parameters




- Select the appropriate parameter file




- The components within the parameter file are displayed
- A selective import
- ... as well as a full import is supported

# Import of control or drive parameters



- If you press “Add to import list” a full import list is generated
- ... and after pressing the button “Import” the parameters are downloaded to the MLC and/or drives


- The progress of this operation is displayed as well as errors during the import





# Import of control or drive parameters

- On completion the following information is displayed:



# Agenda

- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information

## Task system of MLC


- The RTOS permits multi tasking, i.e. several functions (tasks) apparently are executed in parallel
- The different tasks are activated within a very short time span, as a result all tasks seem to be executed simultaneously
- The maximum number of tasks depends on the hardware platform (L25, L45, L65)

### **Concurrent memory access**




If several tasks access global resources (global variables, function blocks etc.), data consistency is an issue, if the data size exceeds the word length of the CPU. The access has to be protected and simultaneous access of another task has to be prevented (e.g. use of semaphores)


# Task types



# Properties of a task



# Task configuration



- The task configuration lists all configured tasks and their properties
- The properties of all existing tasks can be modified
- Additional tasks can be defined

# Default configuration

The screenshot displays the configuration interface for IndraMotion MLC, showing two task configurations: Motion Task and PLC Task. A large red 'SAMPLE' watermark is overlaid on the image.

**Motion Task Configuration:**

- Priorität ( 1..20 ): 2
- Typ: Extern ereignisgesteu (Dropdown)
- Externes Ereignis: EVENT\_OP\_MODE\_MOTION\_CYCLIC (Dropdown)
- Watchdog:
  - Aktivieren
  - Zeit (z.B. t#200ms): T#2ms
  - Empfindlichkeit: 1
- POUs:
  - [Aufruf hinzufügen](#)
  - [Aufruf löschen](#)
  - [POU öffnen](#)
  - [POU wechseln...](#)
  - Nach oben
  - Nach unten


| POU        | Kommentar |
|------------|-----------|
| MotionProg |           |

**PLC Task Configuration:**

- Priorität ( 1..20 ): 5
- Typ: Zyklisch (Dropdown)
- Intervall (z.B. t#200ms): t#10ms
- Watchdog:
  - Aktivieren
  - Zeit (z.B. t#200ms): T#20ms
  - Empfindlichkeit: 3
- POUs:
  - [Aufruf hinzufügen](#)
  - [Aufruf löschen](#)
  - [POU öffnen](#)
  - [POU wechseln...](#)
  - Nach oben
  - Nach unten

| POU     | Kommentar |
|---------|-----------|
| PlcProg |           |

# Default configuration – Timing diagram






## Optimizing the turn-around time for Sercos IOs

- Minimize setting for Sercos cycle time (C-0-0503)
- Add new program sioProg
  - In this program the Sercos IOs are handled
- Add additional task sioTask
  - Priority 2
  - Triggered by external event, event **Sercos cyclic**
  - Activate watchdog (duration depending on setting for Sercos cycle time)
  - Link program sioProg to task sioTask


# Optimizing the turn-around time for Sercos IOs




## Optimizing the turn-around time for onboard IOs

- Add new program oioProg
  - In this program the onboard IOs are handled
- Add additional task oioTask
  - Priority 2
  - Triggered by external event, event **Local Input BitX** or **Local Input Byte**
  - Activate watchdog
  - Link program oioProg to task oioTask

# Optimizing the turn-around time for onboard IOs



# Diagnosing the task system – Cycle times



**Cycle time settings**

Desired MC cycle time (T<sub>cyc</sub>)  us  
 SERCOS-Cycletime  us


**Sensitivity of the motion calculation**

Motion-watchdog sensibility   
 Absolute error counter of the motion   
 Successive errors of the motion

**Motion time display**

|  | Minimum | Current                           | Maximum |    |
|--|---------|-----------------------------------|---------|----|
| Actual MC cycle time (T <sub>cyc</sub> ) |         | <input type="text" value="2000"/> |         | us |
| Time for actual value acquisition        | 33      | 56                                | 75      | us |
| Pausing by motion-synchronous PLC tasks  | 17      | 26                                | 42      | us |
| Time for command value creation          | 13      | 21                                | 29      | us |
| <b>Total time</b>                        | 67      | 105                               | 137     | us |

# Diagnosing the task system – Task List



The task configuration of the project and the control are identical.


| Priority | Type | Name                  | Start Condition    | Watchdog | Sensitivity |
|----------|------|-----------------------|--------------------|----------|-------------|
| 1        |      |                       |                    |          |             |
| 2        | IM   | GATMotionSyncTask     | Motion-synchronous | 2000 µs  | 1           |
| 3        | IM   | Motion calculation    | Cyclic: 2000 µs    | 2000 µs  | 1           |
| 4        |      |                       |                    |          |             |
| 5        | IM   | GATProgTask           | Cyclic: 10000 µs   | 10000 µs | 2           |
| 6        | IM   | GATB ackgroundProg... | Cyclic: 40000 µs   | .....    | .....       |
| 7        |      |                       |                    |          |             |
| 8        |      |                       |                    |          |             |
| 9        |      |                       |                    |          |             |
| 10       |      |                       |                    |          |             |
| 11       |      |                       |                    |          |             |
| 12       |      |                       |                    |          |             |
| 13       |      |                       |                    |          |             |
| 14       |      |                       |                    |          |             |
| 15       |      |                       |                    |          |             |
| 17       |      |                       |                    |          |             |
| 18       |      |                       |                    |          |             |
| 19       |      |                       |                    |          |             |
| 20       |      |                       |                    |          |             |

Increase Priority ▲    ▼ Decrease Priority

**Task types**

- = PLC task (visible in online and offline mode)
- = MLx task (only visible in case of established online connection)
- = C task (only visible in case of established online connection); cannot be modified

# Diagnosing the task system – Task Viewer



# Diagnosing the task system – CPU load

The screenshot shows the software interface for diagnosing the task system. On the left, a tree view shows the project structure with 'MLC\_L65' selected. A context menu is open over 'MLC\_L65', with 'Diagnose' highlighted. A sub-menu is also open, showing 'Erweiterte Eigenschaften' (Advanced Properties) selected. A red 'DRAFT' watermark is overlaid on the image.

The 'Erweiterte Eigenschaften' window displays the following information:

- Hardware:**
  - Seriennummer: SN: 006941214
  - Hardware-Version: CML65-1-3P-504-NA-NNNN-NW
  - Hardware-Details:
 

| Name            | Wert       |
|-----------------|------------|
| HWVersion       | 0x1        |
| FPGAVersion     | 0x10E      |
| MaterialIndexNr | 313        |
| MaterialNr      | R911170899 |
- Versionen:**
  - Firmware: CML65e-MLC-12V08.0366.003
  - 12V08.30
  - SPS-Firmware: IC\_CML65\_BSP\_VX6\_01V24.04
  - Technologiefunktionen: not available
  - Erweiterte Technologiefunktionen: not available
- Aktuelle Werte:**
  - Temperatur:
 

|            |         |
|------------|---------|
| Temperatur |         |
| aktuell    | 41,5 °C |
| maximal    | 41,5 °C |
  - Betriebsstundenzähler: 689,96 h
  - Betriebsstundenzähler, Lüfter: 0,00 h
  - Lüfter ein:
  - Temperaturwarnung:
- CPU-Auslastung:**
  - Warnung ab: 100 %
  - Minimal: 11 %
  - Maximal: 30 %
  - Current CPU load: 23% (indicated by a green bar chart)
  - Min/Max zurücksetzen



## Agenda


- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information

# What is synchronized motion?

- In synchronized motion one or more slave axes follow a master axis
- The rotational angle  $\varphi$  of the master axis (master axis position) is sent to the slave axis
- On the basis of this master axis position a synchronous command position is calculated:
  - $\psi = f(\varphi)$  rotary axis
  - $s = f(\varphi)$  linear axis
- As a result the slave axis follows the master axis synchronously




# Synchronized motion and bus systems



- A prerequisite of synchronous operation is an adequate communication system
- sercos 2 and sercos III offer equidistance
- ... based on TDMA → Time Division Multiple Access
- Fieldbus systems like PROFIBUS DP and DeviceNet don't meet this assumption
- Synchronous operation is not available for PROFIBUS drives!

# Available synchronization modes



# Real master axis

- The master axis position is based on an encoder signal
- For example encoder signal of an IndraDrive connected by sercos to an MLC



# Virtual master axis


- Master axis positions are generated internally on controller level
- ... and transmitted cyclically to the slave axis
- As a result the real slave axes follow this virtual master
- A virtual axis is an imaginary object which exists only in software
- ... and can be controlled with standard PLCopen function blocks or the AxisInterface




Virtual master axis



# Velocity synchronization (1)



# Velocity synchronization (2)




- Execute* → refer to general information on PLCopen
- RationNumerator*, *RatioDenominator* Gear ratio
- MasterFineadjust* Master fine adjust (e.g. tension control)

$$n_{Slave} = n_{Master} \times \frac{n_{RatioNumerator}}{RatioDenominator} \times (1 + MasterFineadjust)$$

- Master* Master axis
- Slave* Slave axis
- InGear* Slave axis in velocity synchronization



# Velocity synchronization (3)



# Velocity synchronization (4)

**ML\_TechInterface.library**

Operation Mode "Velocity Synchronization"

When this operation mode is activated, the drive is operated using an electronic gear with fine adjustment. This functionality causes a velocity synchronization between the master axis and the selected slave axis.

The following command activates the operation mode:

```
arAxisCtrl_gb[].Admin._OpMode.en: = ModeSyncVel;
```

or

```
arAxisCtrl_gb[].Admin._OpMode.b.MODE_SYNC_VEL: = TRUE;
```




The AxisInterface uses the MC\_Power, MC\_GearIn and MC\_GearOut PLCOpen FBs internally to carry out the switchover.

The following table contains the attributes supported by this operation mode:


| Element           | Name                      | Type     | Default | Cyclically scanned |
|-------------------|---------------------------|----------|---------|--------------------|
| arAxisCtrl_gb[ ]  | SyncMode.OutputRevolution | UINT     | 1       | Yes                |
|                   | SyncMode.InputRevolution  | UINT     | 1       | Yes                |
|                   | SyncMode.Fineadjust       | REAL     | 0.0     | Yes                |
|                   | SyncMode.Master           | AXIS_REF |         | Yes                |
|                   | Admin.Axis                | AXIS_REF |         | No                 |
| arAxisStatus_gb[] | Admin.MODE_SYNC_VEL       | BOOL     |         | Not applicable     |

Attributes, operation mode "velocity synchronization"

# Phase synchronization (1)




# Phase synchronization (2)




- Execute → refer to general information on PLCopen
- RationNumerator, RatioDenominator, MasterFineadjust } → refer to MC\_GearIn
- SyncMode** Synchronization direction
- StartMode** Synchronization type (absolute, relative)
- Master Master axis
- Slave Slave axis
- InSync Slave axis in phase synchronization


# Phase synchronization (3)




Master axis




Slave axis



SHORTEST\_WAY  
Shortest way



CATCH\_UP  
Positive direction



SLOW\_DOWN  
Negative direction

# Phase synchronization (4)

**ML\_TechInterface.library**  
Operation Mode "Phase Synchronization"

When this operation mode is activated, the drive is operated using an electronic gear with fine adjustment. This functionality causes a phase synchronization between the master axis and the selected slave axis.

The following command activates the operation mode:

```
arAxisCtrl_gb[].Admin._OpMode.en: = ModeSyncPhase;
or
arAxisCtrl_gb[].Admin._OpMode.b.MODE_SYNC_PHASE: = TRUE;
```



The AxisInterface uses the MC\_Power, MB\_GearInPos, MC\_GearOut and MB\_PhasingSlave PLCopen FBs internally to carry out the switchover.

The following table contains the attributes supported by this operation mode:



| Element           | Name                      | Type              | Default      | Cyclically scanned |
|-------------------|---------------------------|-------------------|--------------|--------------------|
| arAxisCtrl_gb[ ]  | SyncMode.OutputRevolution | UINT              | 1            | Yes                |
|                   | SyncMode.InputRevolution  | UINT              | 1            | Yes                |
|                   | SyncMode.Fineadjust       | REAL              | 0.0          | Yes                |
|                   | SyncMode.SyncDirection    | MC_SYNC_DIRECTION | SHORTEST_WAY | Yes                |
|                   | SyncMode.StartMode        | MC_START_MODE     | ABSOLUTE     | No                 |
|                   | SyncMode.Master           | AXIS_REF          |              | Yes                |
|                   | Admin.Axis                | AXIS_REF          |              | No                 |
|                   | SyncMode.PhaseOffset      | REAL              | 0.0          | Yes                |
|                   | SyncMode.PhaseOffsetVel   | REAL              | 1.0          | No                 |
|                   | SyncMode.PhaseOffsetAcc   | REAL              | 100.0        | No                 |
| arAxisStatus_gb[] | Admin.MODE_SYNC_PHASE     | BOOL              |              | Not applicable     |
|                   | SyncMode.PhasingSlaveDone | BOOL              |              | Not applicable     |

# Agenda

- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information


# Cams

- For complex non-linear motion profiles
- Generate rotary or linear slave axis movement
- ... depending on a master axis
- Master signal is rotary angle  $\varphi$  (generally)






# Cams – Examples (1)




Source: [www.wikipedia.de](http://www.wikipedia.de)


# Cams – Examples (2)




# Cams – Examples (3)



# Cams – Overview




# Cam table



↓ Point table

|               |           |            |            |  |  |  |     |
|---------------|-----------|------------|------------|--|--|--|-----|
| $\phi$ [Grad] | 0         | 10         |            |  |  |  |     |
| $r$ [%]       | 0         |            |            |  |  |  |     |
|               | 358,59375 | 358,945313 | 359,296875 |  |  |  | 360 |
|               | 0         | 0          | 0          |  |  |  | 0   |

↓ Interpolation



- Cam table describes coupling of master axis and slave axis
- Calculation of slave axis positions is determined by interpolation between discrete table positions


### IndraDrive

- 4 tables with 1024 points
- 4 tables with 128 points
- Cubic spline interpolation is used to calculate intermediate slave axis positions
- Values are normalized (Percentage values)
- Cam shaft distance as additional parameter

## Cam table


- ✓ Simple and clear function
- ✓ Low computing effort  
All the coefficients required for spline interpolation are determined in a calculation that is made before the time of execution
- ✓ The slave axis position can then be determined very easily during runtime
- ✓ Suitable if no online modification is required
- ✓ Easy data exchange with 3<sup>rd</sup> party tools
- ✗ All polynomial coefficients must be recalculated after a support point is changed
- ✗ Large data amounts

# Motion Profile




- Mathematical function describes motion curve („Formula“)
- These motion rules describe the coupling of slave axis and master axis as an analytical function
- The complete motion profile is defined step-by-step using motion rules
- A step with the associated motion rule is called “motion step”
- For more details on motion rules refer to VDI 2143
- Mainly polynomial functions of the 5<sup>th</sup> order or higher are used

# Motion Profile




- 2 Motion profiles per axis with up to 16 steps
- Point tables still can be used within a motion profile
- 99 Point tables with 1024 points
- Processing in PLC program by function blocks
  - MB\_MotionProfile
  - MB\_ChangeProfileSet
  - MB\_ChangeProfileStep
  - MB\_ChangeCamData






# Centralized and decentralized Cam concept



## Motion Profile



- ✓ Low amounts of data  
The required information is limited to only the specification of the boundary values of the individual motion steps
- ✓ Easy online modification  
The individual motion steps easily can be modified independent of other motion steps
- ✓ Only drives with basic operation required  
Drives with PackProfile are adequate
- ✗ Increased computing effort at runtime

# FlexProfile




- 4 FlexProfiles per axis
- Max. 64 steps described by motion rules or point tables with max. 1024 points
- Processing in PLC program by function blocks

- ML\_FlexProfile
- MB\_ChangeFlexProfileSet
- MB\_ChangeFlexEventSet
- MB\_ChangeCamData



# FlexProfile – Basic Features



- Compose up to 16 motion steps to a FlexProfile
- Free scaling of master axis (no restriction to 360°)
- Free scaling of slave axis (no restriction to 360°)
- Relative definition of master axis section and stroke
- Time controlled motion supported
- Rich set of motion rules (cf. VDI 2143 and extended motion rules)

# FlexProfile – Standardized Motion rules (VDI 2143)

## Rest → Rest

- Standstill \*
- Simple sinoid (simple sine curve) \*
- Besthorn sinoid (offset sine curve)
- Acceleration-optimized offset sine curve \*
- Torque-optimized offset sine curve \*
- Gutman sinoid \*
- Modified sinoid \*
- Modified acceleration trapezoid \*
- 5<sup>th</sup>-degree polynomial
- 7<sup>th</sup>-degree polynomial \*

## Velocity → Velocity

- Linear interpolation
- 5<sup>th</sup>-degree polynomial
- 7<sup>th</sup>-degree polynomial \*
- Modified sinoid \*

## Rest → Velocity

- 5<sup>th</sup>-degree polynomial
- 7<sup>th</sup>-degree polynomial \*

## Velocity → Rest


- 5<sup>th</sup>-degree polynomial
- 7<sup>th</sup>-degree polynomial \*

## General motion

- 5<sup>th</sup>-degree polynomial
- 7<sup>th</sup>-degree polynomial \*


\*) only with FlexProfile

# FlexProfile – Motion Rules (examples)



- Rest in Rest 5<sup>th</sup>-degree polynomial (Position, velocity and acceleration)
- Rest in Rest, simple sinoid (Position, velocity and acceleration)


# FlexProfile – Motion Rules (examples)




- Rest in Velocity 5<sup>th</sup>-degree polynomial (position)
- Velocity in Rest 5<sup>th</sup>-degree polynomial (position)
- Velocity in Velocity 5<sup>th</sup>-degree polynomial (Position, velocity and acceleration)

# FlexProfile – Supplemental Motion rules

## Standardized motion rules according to VDI 2143




Master axis section




## Supplemental motion rules

- Acceleration-limited motion (trapezoid profile)
- Acceleration-limited sinoid
- Jerk-limited motion




Master axis section results






# FlexProfile – Supplemental Motion rules

Polynomial 5<sup>th</sup> order with velocity limitation




Polynomial with damped oscillation




# FlexProfile – Execution mode

- **Cyclic execution mode**




- **Single shot execution mode**




# FlexProfile – Switching

- **Switching on angle**




- **Immediate Switching**




# FlexProfile – Switching

- **Hard switching**




- **Soft switching**



# FlexProfile – Events

**Events** can be attached to sections. Events consist of Trigger and Action




**Example:** Coordination of motion movements

- Trigger:**
- Relative / Absolute **master position** respectively **Time** reached
  - Relative / Absolute **slave position** reached
  - **PLC** Signal


# FlexProfile – Events

## Actions

- Set bit immediately
- Set bit at end of step
- Set bit at end of profile
- Set bit immediately with transition to next step



# FlexProfile – Events




An Event with Event Condition “PLC signal” is fired with a bit in `AxisData[.].dwFlexEventControlBits_q`

The bit number correlates with the event number! Please note that the event number sometimes is displayed 0-based and on other screens 1-based!

The events can be checked using `AxisData[.].dwFlexEventStatusBits_i`


Define a high-prior task to evaluate these events (motion driven and priority higher then MotionTask)!

# FlexProfile – Time controlled motion



### Flex Step


- Dynamic motion step
- Motion curve adapted at runtime
- ... according to the margin values of adjacent motion steps
- Reestablishes relation to master axis position






# FlexProfile – Flex Step types


- Flex Step with relative stroke and relative master axis section
- Flex Step with relative stroke and absolute master axis section
- Flex Step with absolute stroke and relative master axis section
- Flex Step with absolute stroke and absolute master axis section




Flex step with a relative stroke and a relative master axis section



Flex step with an absolute stroke and a relative master axis section




Flex step with a relative stroke and an absolute master axis section




Flex step with an absolute stroke and an absolute master axis section




# FlexProfile – Time controlled motion





Duration of time controlled step remains constant in spite of modification of master axis velocity!





# FlexProfile – Overview on Function Blocks

|   |   |
|---|---|
| <p><b>MB_ChangeFlexProfileSet</b><br/>Setup and write FlexProfile</p>           |  |
| <p><b>MB_ChangeFlexEventSet</b><br/>Define Events and assign them to a step</p> |  |
| <p><b>MB_ChangeCamData</b><br/>Write Point table in to the MLC</p>              |  |
| <p><b>ML_FlexProfile</b></p>  | <p>Activate a FlexProfile</p>   |


# FlexProfile – Example cross sealing






# FlexProfile – Example cross sealing



# FlexProfile – Example bottling machine








ST - Punching time  
 FT - Forming time  
 SB – Punching movement V,A,J




# Point table – Motion Profile – FlexProfile




## Point tables

- Drive feature
- 4 point tables per axis with max. 1024 points
- **Only for real axes**



## Motion Profile

- Control feature
- 2 motion profiles per axis with up to 16 motion steps
- Always related to master axis position



## FlexProfile

- Control feature
- 4 FlexProfiles per axis with up to 16 motion steps
- Related to master axis position or to time
- Relative or absolute reference of master and slave axis
- Variable switching/synchronization of profiles
- Event handling




# Agenda

- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information


# CamBuilder – Overview

- CamBuilder is a graphical tool for creation and modification of Cams
- Suitable for
  - IndraDrive
  - IndraMotion MLD and
  - IndraMotion MLC/XLC
- Operations
  - Graphical creation and modification of Cams
  - Download and upload of Cams to/from IndraDrive, IndraMotion MLD and IndraMotion MLC/XLC
  - Import and export of Cams in different formats (Excel, XML, parameter file \*.par)
- CAM Builder is integral part of IndraWorks
- A license code has to be entered for activation


# Flexible use of Cams



# Licensing of CamBuilder




- Select menu entry Tools/Options
- Select General/Software licenses
- The current licensing state is displayed




- You can activate a 30 days demo license
- ... or enter a license key and activate a full license

# Licensing of CamBuilder




- Accept the terms of license



- The license status of CamBuilder is “Licensed”

# Using the CamBuilder

- After activation of the CamBuilder and opening the group “CamBuilder” in the Device Library you can add the following elements to you project:



### Cam

Add a Cam to your CamPool to create your own motion curves. Cam tables, MotionProfiles and FlexProfile are supported

### CamPool

CamPool is subfolder in your IndraWorks project which is used as a storage for all your motion curves (Cam tables, Motion profiles and FlexProfiles)

### Preview

Multiple motion curves can be combined to a Preview to see several axes in correlation to another

# CAM Builder – Motion Step Editor





Sequence of motion steps

Settings for selected motion step

- Easy composition of CAM profile by a sequence of motion steps
  - Definition of position-related motion steps, and
  - Definition of time-related motion-steps
- ☞ Graphical creation and modification of FlexProfiles




# Add CAM Pool to project





- 1 Open Group CamBuilder in Library
- 2 Select "CamPool"
- 3 Add CamPool to IndraWorks Project

# How to create a FlexProfile (1)




# How to create a FlexProfile (2)



- 1 Create new Cam
- 2 Enter name "Horizontal"
- 3 Application specific wizard: None
- 4 Translatory scaling (mm)
- 5 Press "Finish" button

# How to create a FlexProfile (3)



- 1 Enter master axis velocity
- 2 Switch Edit mode to "Relative"
- 3 Enter stroke value of slave axis
- 4 Enter master axis section
- 5 Motion law "Rest in Velocity – Poly5"
- 6 Enter velocity value

**Motion Step Editor - Horizontal**

Master axis velocity: 4 rpm

| No | Reference | ΔY [mm] | ΔX [deg] | ΔT [ms] |
|----|-----------|---------|----------|---------|
| 1  | ▼         | 15      | 15       | 625     |

Step Type: Standard step

Motion Law: Rest in Velocity - Polynomial 5th order

Startpoint: X1: 0 deg, Y1: 0 mm, V1: 0 mm/min, A1: 0 mm/sec², J1: 614.4 mm/sec³

Endpoint: X2: 15 deg, Y2: 15 mm, V2: 3000 mm/min, A2: 0 mm/sec², J2: -921.6 mm/sec³

Motion step maxima: Vmax: 3000 mm/min, Amax: 121.177 mm/sec², Jmax: -921.6 mm/sec³, Cmdyn: 4130.6779 mm³/sec³

Turning Point Displacement: 0.50000

# How to create a FlexProfile (4)



- 1 Add motion step after highlighted step
- 2 Select Reference to Time
- 3 Enter stroke value for slave axis
- 4 Enter duration of step
- 5 Motion law  
"Velocity in Velocity – Constant velocity"

| No | Reference | $\Delta Y$ [mm] | $\Delta X$ [deg] | $\Delta T$ [ms] |
|----|-----------|-----------------|------------------|-----------------|
| 1  |           | 15              | 15               | 625             |
| 2  |           | 400             | 192              | 8000            |

Step Type: Standard step

Motion Law: Velocity in Velocity - Constant velocity

Startpoint: X2: 15 deg, Y2: 15 mm, V2: 3000 mm/min, A2: 0 mm/sec<sup>2</sup>, J2: 0 mm/sec<sup>2</sup>

Endpoint: X3: 207 deg, Y3: 415 mm, V3: 3000 mm/min, A3: 0 mm/sec<sup>2</sup>, J3: 0 mm/sec<sup>2</sup>

Motion step maxima: Vmax: 3000 mm/min, Amax: 0 mm/sec<sup>2</sup>, Jmax: 0 mm/sec<sup>2</sup>, Cmdyn: 0 mm<sup>2</sup>/sec<sup>2</sup>

Turning Point Displacement: 0.50000

# How to create a FlexProfile (5)



- 1 Add motion step after highlighted step
- 2 Select Reference to Master axis position
- 3 Enter Slave axis stroke value (-415)
- 4 Enter Master axis Endpoint (360)
- 5 Set velocity value to zero
- 6 Select FlexStep with relative distance and absolute master axis range

| No | Reference | $\Delta Y$ [mm] | $\Delta X$ [deg] | $\Delta T$ [ms] |
|----|-----------|-----------------|------------------|-----------------|
| 1  |           | 15              | 15               | 625             |
| 2  |           | 400             | 192              | 8000            |
| 3  |           | -415            | 153              | 6375            |

Master axis velocity: 4 rpm

Step Type: FlexStep with relative distance and absolute master axis range

Motion Law: General Motion - Polynomial 5th order

Startpoint: X3: 207 deg, Y3: 415 mm, V3: 3000 mm/min, A3: 0 mm/sec<sup>2</sup>, J3: 0 mm/sec<sup>3</sup>


Endpoint: X4: 360 deg, Y4: 0 mm, V4: 0 mm/min, A4: 0 mm/sec<sup>2</sup>, J4: 0 mm/sec<sup>3</sup>

Motion step maxima: Vmax: -8698.3846 mm/min, Amax: -89.5632 mm/sec<sup>2</sup>, Jmax: -138.9521 mm/sec<sup>3</sup>, Cmdyn: 7131.5593 mm<sup>3</sup>/sec<sup>3</sup>

Turning Point Displacement: 0.50000

Description:

# How to create a FlexProfile (6)



# How to create a FlexProfile (7)

**1** Create new Cam

**2** Enter name “Vertical”


**3** Application specific wizard: None

**4** Translatory scaling (mm)

**5** Press “Finish” button




# How to create a FlexProfile (8)



| No | Reference | ΔY [mm] | ΔX [deg] | ΔT [ms] |
|----|-----------|---------|----------|---------|
| 1  |           | 0       | 15       | 625     |

# How to create a FlexProfile (9)



Motion Step Editor - Vertical

Master axis velocity 1 rpm

| No | Reference | $\Delta Y$ [mm] | $\Delta X$ [deg] | $\Delta T$ [ms] |
|----|-----------|-----------------|------------------|-----------------|
| 1  |           | 0               | 15               | 2500            |
| 2  |           | -140            | 60               | 10000           |

Step Type: Standard step

Motion Law: Rest in Rest - Polynomial 5th order

Startpoint: X2 15 deg, Y2 0 mm, V2 0 mm/min, A2 0 mm/sec<sup>2</sup>, J2 -8.4 mm/sec<sup>2</sup>


Endpoint: X3 75 deg, Y3 -140 mm, V3 0 mm/min, A3 0 mm/sec<sup>2</sup>, J3 -8.4 mm/sec<sup>2</sup>

Motion step maxima: Vmax -1574.9992 mm/min, Amax 8.0829 mm/sec<sup>2</sup>, Jmax -8.4 mm/sec<sup>2</sup>, Cmdyn 131.2075 mm<sup>2</sup>/sec<sup>4</sup>

Turning Point At 45 deg 0.50000

Description

# How to create a FlexProfile (10)



- 1 Add motion step after highlighted step
- 2 Select Reference to Time
- 3 Enter stroke value for slave axis
- 4 Enter duration of step
- 5 Motion law "Rest in Rest – Standstill"

Motion Step Editor - Vertical

Master axis velocity 4 rpm

| No | Reference | ΔY [mm] | ΔX [deg] | ΔT [ms] |
|----|-----------|---------|----------|---------|
| 1  |           | 0       | 15       | 625     |
| 2  |           | -140    | 60       | 2500    |
| 3  |           | 0       | 90       | 3750    |

Step Type: Standard step

Motion Law: Rest in Rest - Standstill

Startpoint: X3 75 deg, Y3 -140 mm, V3 0 mm/min, A3 0 mm/sec², J3 0 mm³/sec³

Endpoint: X4 165 deg, Y4 -140 mm, V4 0 mm/min, A4 0 mm/sec², J4 0 mm³/sec³

Motion step maxima: Vmax 0 mm/min, Amax 0 mm/sec², Jmax -537.6 mm³/sec³, Cmdyn 0 mm³/sec³

Turning Point Displacement: 0.50000

Description:

# How to create a FlexProfile (11)



Motion Step Editor - Vertical

Master axis velocity 4 rpm

| No | Reference | $\Delta Y$ [mm] | $\Delta X$ [deg] | $\Delta T$ [ms] |
|----|-----------|-----------------|------------------|-----------------|
| 1  |           | 0               | 15               | 625             |
| 2  |           | -140            | 60               | 2500            |
| 3  |           | 0               | 90               | 3750            |
| 4  |           | 140             | 60               | 2500            |

Step Type: FlexStep with relative distance and absolute master

Motion Law: General Motion - Polynomial 5th order

| Startpoint |                       | Endpoint |                       |
|------------|-----------------------|----------|-----------------------|
| X4         | 165 deg               | X5       | 225 deg               |
| Y4         | -140 mm               | Y5       | 0 mm                  |
| V4         | 0 mm/min              | V5       | 0 mm/min              |
| A4         | 0 mm/sec <sup>2</sup> | A5       | 0 mm/sec <sup>2</sup> |
| J4         | 0 mm/sec <sup>3</sup> | J5       | 0 mm/sec <sup>3</sup> |


Motion step maxima

|        |  |
|--------|--|
| Vmax   | 6299.8916 mm/min                           |
| Amax   | 129.3258 mm/sec <sup>2</sup>               |
| Jmax   | 528.1686 mm/sec <sup>3</sup>               |
| Cmddyn | 8397.283 mm <sup>3</sup> /sec <sup>4</sup> |

Turning Point Displacement: 0.50000

Description:

# How to create a FlexProfile (12)



**Motion Step Editor - Vertical**

Master axis velocity: 4 rpm

| No | Reference | $\Delta Y$ [mm] | $\Delta X$ [deg] | $\Delta T$ [ms] |
|----|-----------|-----------------|------------------|-----------------|
| 1  |           | 0               | 15               | 625             |
| 2  |           | -140            | 60               | 2500            |
| 3  |           | 0               | 90               | 3750            |
| 4  |           | 140             | 60               | 2500            |
| 5  |           | 0               | 135              | 5625            |

Step Type: Standard step

Motion Law: Rest in Rest - Standstill

Startpoint: X5: 225 deg, Y5: 0 mm, V5: 0 mm/min, A5: 0 mm/sec<sup>2</sup>, J5: 0 mm/sec<sup>3</sup>



Endpoint: X6: 360 deg, Y6: 0 mm, V6: 0 mm/min, A6: 0 mm/sec<sup>2</sup>, J6: 0 mm/sec<sup>3</sup>

Motion step maxima: Vmax: 0 mm/min, Amax: 0 mm/sec<sup>2</sup>, Jmax: 0 mm/sec<sup>3</sup>, Cmdyn: 0 mm<sup>2</sup>/sec<sup>4</sup>

Turning Point Displacement: 0.50000

Description:

# How to create a Preview



- 1 Open Group CamBuilder in Library
- 2 Select "Preview"
- 3 Add Preview to CamPool

# How to create a Preview



The screenshot displays the 'Preview' window of the IndraMotion MLC software. It features three vertically stacked graphs and three corresponding settings panels on the right.

- Masteraxis (Velocity: 4 rpm):** The graph shows a red line representing a velocity profile that increases linearly from 0 to 300 deg over 15000 ms, then drops sharply. The settings panel for this profile includes:
  - Velocity: 4.0000 rpm
  - Preview time: 16000 ms
  - Modulo: 360 deg
  - Scaling: Rotatory (deg)
- Horizontal (0 ms | 0 mm):** The graph shows a red line for a position profile that increases to a peak of 446.59 mm at approximately 10000 ms before returning to 0 mm. The settings panel includes:
  - Modulo: 0 mm
  - Master offset: 0.0000 mm
  - Slave offset: 0.0000 mm
- Vertical (0 ms | 0 mm):** The graph shows a red line for a position profile that remains at 0 mm until approximately 10000 ms, then moves to -100 mm. The settings panel includes:
  - Modulo: 0 mm
  - Master offset: 0.0000 mm
  - Slave offset: 0.0000 mm


Arrows indicate the relationship between the settings panels and the corresponding profiles in the graphs. A large 'SIDE' watermark is visible across the center of the image.

Add profiles to preview by drag & drop and modify settings

# Download FlexProfile for 1<sup>st</sup> axis






- 1 Select "Download to Device ..."
- 2 Select "FlexProfile 0" for 1st axis
- 3 After download to MLC an information is displayed







# Download FlexProfile for 1<sup>st</sup> axis



- 1 Double click on “FlexProfile”
- 2 Push “FlexProfile overview” button
- 3 The 1st FlexProfile is stored on MLC, has been checked and is OK!

# Download FlexProfile for 2<sup>nd</sup> axis



- 1 Select "Download to Device ..."
- 2 Select "FlexProfile 0" for 2nd axis
- 3 After download to MLC an information is displayed



# Download FlexProfile for 2<sup>nd</sup> axis

**1** Double click on “FlexProfile”

**2** Push “FlexProfile overview” button

**3** The 2nd FlexProfile is stored on MLC, has been checked and is OK!

| FlexProfile State | Select                           | Active                | Checked                          | OK                               |
|-------------------|----------------------------------|-----------------------|----------------------------------|----------------------------------|
| 0                 | <input checked="" type="radio"/> | <input type="radio"/> | <input checked="" type="radio"/> | <input checked="" type="radio"/> |
| 1                 | <input type="radio"/>            | <input type="radio"/> | <input type="radio"/>            | <input type="radio"/>            |
| 2                 | <input type="radio"/>            | <input type="radio"/> | <input type="radio"/>            | <input type="radio"/>            |
| 3                 | <input type="radio"/>            | <input type="radio"/> | <input type="radio"/>            | <input type="radio"/>            |

| 4 1/min               | Details...  | Events...                    |
|-----------------------|-------------|------------------------------|
| Master axis range (-) | Distance... | Slave axis velocity (mm/min) |
| 15                    | 0           | 0                            |
| 60                    | -140        | 0                            |
| 3750                  | 0           | 0                            |
| 225                   | 140         | 0                            |
| 135                   | 0           | 0                            |

# Agenda


- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – FlexProfile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information

# IMST – Documentation

- Complete Documentation of IndraMotion Service Tool
- ... available on the media directory
- or in print format
- in German and English language




# IMST – IndraMotion Service Tool











# IMST – IndraMotion Service Tool

- Easy access using a browser to control and drive data without IndraWorks
- Integrated into runtime system of IndraMotion MLC
- Basic configuration and tool for simplified maintenance and commissioning
- Ease of use by navigation in a tree structure, toolbar and tooltips
- Integrated user management
  - Access privileges depending on current user level
  - Flexible definition of user groups
  - Individual adjustment of privileges



## IMST – IndraMotion Service Tool

- Status and diagnosis of control hardware, drives and communication interfaces
- Parameter editor
- Access to PLC variables
- User-specific lists (Hardware, Firmware, Serial number)
- Simple Oscilloscope operation






# Agenda

- System topology and system components
- IndraWorks supported operation systems
- First steps with IndraWorks
- Parameter system
- Motion Programming Basics
- MLC Diagnosis system
- Sercos – the automation bus
- Data backup and restore
- Task System
- Synchronized Motion
- Electronic CAMs: Point table – MotionProfile – Flex Profile
- CamBuilder
- IMST – IndraMotion Service Tool
- Additional sources of information

# MLC Documentation

- All MLC manuals for released MLC versions are available in the Intranet on the media directory




[www.boschrexroth.com/mediadirectory](http://www.boschrexroth.com/mediadirectory)

- MLC manuals for the current version can be found on the installation DVD IndraWorks MLC



- The Online Help system provides the same information



# IndraMotion MLC and IndraLogic XLC

Marzo 2016 • Rocio Sevilla

Thank you!

